




JXiQ™ Gas-Fired Pool and Spa Heater

Model Size 200, 260, 400

ASME Compliant Model Size 260 & 400

Essential installation and startup instructions are included in this manual. Additional operation and troubleshooting information is available online by scanning the QR code with your phone or visiting jandy.com



⚠ WARNING

IF THE INFORMATION IN THESE INSTRUCTIONS ARE NOT FOLLOWED EXACTLY, A FIRE OR EXPLOSION MAY RESULT, CAUSING PROPERTY DAMAGE, PERSONAL INJURY, OR DEATH.

FOR YOUR SAFETY: This product must be installed and serviced by a contractor who is licensed and qualified in pool equipment by the jurisdiction in which the product will be installed where such state or local requirements exists. In the event no such state or local requirement exists, the installer or maintainer must be a professional with sufficient experience in pool equipment installation and maintenance so that all of the instructions in this manual can be followed exactly. Before installing this product, read and follow all warning notices and instructions that accompany this product. Failure to follow warning notices and instructions may result in property damage, personal injury, or death. Improper installation and/or operation can create carbon monoxide gas and flue gases which can cause serious injury, property damage, or death. For indoor installations, as an additional measure of safety, Zodiac Pool Systems LLC strongly recommends installation of suitable carbon monoxide detectors in the vicinity of this appliance and in any adjacent occupied spaces. Improper installation and/or operation may void the warranty.

If the information in these instructions is not followed exactly, a fire or explosion may result causing property damage, personal injury or death.

Do not store or use gasoline or other flammable vapors and liquids in the vicinity of this or any other appliance.

WHAT TO DO IF YOU SMELL GAS

- Immediately switch off main gas supply.
- Do not try to light any appliance.
- Do not touch any electrical switch; do not use any phone in your building.
- Immediately call your gas supplier from a neighbor's phone. Follow the gas supplier's instructions.
- If you cannot reach your gas supplier, call the fire department.

Installation and service must be performed by a qualified installer, service agency or the gas supplier.

Table of Contents

Section 1. Important Safety Instructions and General Information	3	Section 8. Bluetooth® Pairing	39
1.1 Safety Instructions	3	Section 9. Operating Instructions	40
1.2 Warranty	4	9.1 Important Safety Information	40
1.3 General Operation Description	4	9.2 First-Time Start-Up Procedure	40
1.4 Specifications	5	9.3 To Turn Off Gas to the Heater	41
1.5 Dimensions	6	9.4 Normal Operation	41
1.6 Certification Codes and Standards	6	9.5 Operating the Controller	41
1.7 Heater Components	7	9.6 Performing Seasonal Shutdown	43
Section 2. Getting Started	8	Section 10. Maintenance	43
2.1 Package Contents	9	10.1 Water Chemistry	44
2.2 Required Equipment	10	10.2 Swimming Pool Energy Saving Tips	45
Section 3. Location Requirements	11	10.3 Winterizing	45
3.1 Clearances	11	10.4 Spring Start-up	45
3.2 Outdoor Installation	12	10.5 Inspection and Service	45
3.3 Indoor and Outdoor Shelter Installation	13	Section 11. Troubleshooting	47
Section 4. Gas Connections	22	11.1 Common Problems	47
4.1 Supply Gas Requirements	22	11.2 Service Diagnostic Messages	48
4.2 Inlet Gas Pressure Test	23	11.3 Ignition Control LED Service Codes	50
4.3 Special Precautions for LP Gas	24	Section 12. Professional Service and Maintenance	50
Section 5. Water Connections	25	12.1 Header Bypass Reassembly Recommendations	51
5.1 Pump Sizing	25	Section 13. Spare Parts	51
5.2 Plumbing Connections	26	13.1 Major Components	52
5.3 Sacrificial Anode Replacement	29	13.2 Cabinet Assembly Spare Parts List and Exploded Parts Diagram	53
5.4 Water Pressure Switch Adjustment	29	13.3 Heat System Spare Parts List and Exploded Parts Diagrams	54
5.5 Check Valve Installation	30	13.4 Water System Spare Parts List and Exploded Parts Diagrams	56
5.6 Pressure Relief Valve Installation	30	13.5 Electrical System Spare Parts List and Exploded Parts Diagrams	57
5.7 Auxiliary Components, Chlorinators, Ozone Generators and Sanitizing Chemicals	32	Section 14. Appendix A. ASME® Compliant Header	58
Section 6. Electrical Connections	32	14.1 Dimensions	58
6.1 Service Access	33	14.2 Package Contents	58
6.2 Main Wiring Connections	33	14.3 Pump Sizing	59
6.3 Bonding	35	14.4 Cabinet Assembly Spare Parts List and Exploded Parts Diagram	62
Section 7. Optional Remote Controls	35	14.5 Water System Spare Parts List and Exploded Parts Diagrams	64
7.1 Connecting to a Remote Pool-Off-Spa Selector (3-Wire Connection)	35		
7.2 Connecting to an AquaLink® Control System or Remote TSTAT (2-Wire Connection)	35		
7.3 "Smart" Communication via RS-485	36		

EQUIPMENT INFORMATION RECORD

Date of Installation _____

Installer Information _____

Initial Pressure Gauge Reading (with Clean Filter) _____

Pump Model _____ Horsepower _____

Notes _____

Section 1. Important Safety Instructions and General Information

READ THE SAFETY, INSTALLATION AND OPERATION INSTRUCTIONS COMPLETELY BEFORE PROCEEDING WITH THE INSTALLATION.

This manual provides safety, installation and operation instructions for the Jandy JXIQ pool and spa gas heater product line.

1.1 Safety Instructions

Consumer information – the heater is designed and manufactured to provide many years of safe and reliable service when installed, operated, and maintained according to the information in this manual and the installation codes referred to throughout. Be sure to read and comply with all warnings and cautions.

WARNING

Do not store or use gasoline or other flammable vapors and liquids in the vicinity of this or any other appliance.

WHAT TO DO IF YOU SMELL GAS

- Immediately switch off main gas supply.
- Do not try to light any appliance.
- Do not touch any electrical switch; do not use any phone in your building.
- Immediately call your gas supplier from a neighbor's phone. Follow the gas supplier's instructions.
- If you cannot reach your gas supplier, call the fire department.

Installation and service must be performed by a qualified installer, service agency or the gas supplier.

WARNING

FOR YOUR SAFETY – This product must be installed and serviced by a contractor who is licensed and qualified in pool equipment by the jurisdiction in which the product will be installed where such state or local requirements exist. The maintainer must be a professional with sufficient experience in pool equipment installation and maintenance so that all of the instructions in this manual can be followed exactly. Before installing this product, read and follow all warning notices and instructions that accompany this product. Failure to follow warning notices and instructions may result in property damage, personal injury, or death. Improper installation and/or operation may void the warranty.

Improper installation and/or operation can create unwanted electrical hazard which can cause serious injury, property damage, or death.



ATTENTION INSTALLER – This manual contains important information about the installation, operation and safe use of this product. This information should be given to the owner/operator of this equipment.

WARNING

Improper installation or maintenance can cause nausea or asphyxiation from carbon monoxide in flue gases which could result in severe injury, or death. For indoor installations, as an additional measure of safety, Zodiac Pool Systems LLC strongly recommends the installation of suitable carbon monoxide detectors in the vicinity of this appliance and in any adjacent occupied spaces.

⚠ WARNING

The following "Safety Rules for Hot Tubs", recommended by the U.S. Consumer Product Safety Commission, should be observed when using the spa. Consult heater operation and installation instructions for water temperature guidelines before setting temperature.

- Spa or hot tub water temperature should never exceed 104°F (40°C). One hundred degrees Fahrenheit (100°F (38°C)) is considered safe for a healthy adult. Special caution is recommended for young children.
- The drinking of alcoholic beverages before or during spa or hot tub use can cause drowsiness which could lead to unconsciousness, and subsequently result in drowning.
- **Pregnant women take note!** Soaking in water above 102°F (38.5°C) can cause fetal damage during the first three (3) months of pregnancy (which could result in the birth of a brain-damaged or deformed child). If pregnant women are going to use a spa or hot tub, they should make sure the water temperature is below 100°F (38°C) maximum.
- The water temperature should always be checked with an accurate thermometer before entering a spa or hot tub. Temperature controls may vary by as much as 1°F/1°C.
- Persons with a medical history of heart disease, diabetes, circulatory or blood pressure problems should consult their physician before using a hot tub or spa.
- Persons taking any medication which induces drowsiness (e.g., tranquilizers, antihistamines, or anticoagulants) should not use spas or hot tubs.

Prolonged immersion in hot water can induce hypothermia.

Hypothermia occurs when the internal body temperature reaches a level several degrees above the normal body temperature of 98.6°F (37°C). Symptoms include dizziness, fainting, drowsiness, lethargy, and an increase in the internal body temperature. The effects of hypothermia include:

- Lack of awareness of impending hazard
- Failure to perceive heat
- Failure to recognize need to leave spa
- Physical inability to leave spa
- Fetal damage in pregnant women
- Unconsciousness resulting in a danger of drowning

SAVE THESE INSTRUCTIONS

1.2 Warranty

This heater is sold with a limited factory warranty. Details are included with this heater.

Make all warranty claims to a Fluidra® Dealer or directly to the factory. Claims must include the heater serial number and model (this information can be found on the rating plate), installation date, and name of the installer. Shipping costs are not included in the warranty coverage.

The warranty does NOT cover damage caused by improper assembly, installation, operation or field modification. Also, damage to the heat exchanger by corrosive water is NOT covered by the warranty.

NOTE: Keep this manual in a safe place for future reference when inspecting or servicing the heater.

1.3 General Operation Description

The blower draws air and fuel through specially designed orifices, delivering a precise mixture to the burner, located inside the sealed combustion chamber. Water flows through the heat exchanger, which surrounds the burner transferring the heat to the water. Exhaust gases are then directed through a duct where it is vented to the atmosphere.

1.4 Specifications

SUPPLY GAS			
Installation Location*	NATURAL GAS (NG)	CERTIFIED INDOOR, OUTDOOR / COVERED SHELTER	
	LIQUID PROPANE (LP)	OUTDOOR / COVERED SHELTER	
Outdoor Operation Ambient Air	ANY	OUTDOOR OPERATION IN AMBIENT AIR DOWN TO 40°F (4°C)	
Gas Pipe/Heater Gas Valve Connection†	NATURAL GAS (NG)	3/4 in NPT	
	LIQUID PROPANE (LP)		
Inlet Gas Supply Pressure ‡		Min	Max
	NATURAL GAS (NG)	4.0 in WC	10.5 in WC
	LIQUID PROPANE (LP)		14.0 in WC
Water Pipe/Heater Connection	NATURAL GAS (NG)	- PVC/CPVC 2-inch unthreaded. - Jandy Threaded union	
	LIQUID PROPANE (LP)		
Water Flow Rate		Min	Max
	NATURAL GAS (NG)	30 gpm (76 lpm)	100 gpm (454 lpm)
	LIQUID PROPANE (LP)		
Working Water Pressure			Max
	NATURAL GAS (NG)	2 psi**	50 psi (STANDARD) 75 psi (ASME)
	LIQUID PROPANE (LP)		
Exhaust Vent Connection Size (Category I§. See Section 3.3, Indoor and Outdoor Shelter Installation)	NATURAL GAS (NG)	- Model 200: 6 in - Model 260: 7 in - Model 400: 8 in	
	LIQUID PROPANE (LP)		
Exhaust Vent Connection Size (Category II§. See Section 3.3, Indoor and Outdoor Shelter Installation)	NATURAL GAS (NG)	All Models: 4 in	
	LIQUID PROPANE (LP)		
Electrical Supply	NATURAL GAS (NG)	120 VAC@ <5amps 240 VAC@ <2.5amps	
	LIQUID PROPANE (LP)		
High Altitude:	NATURAL GAS (NG)	Appliances are normally derated when installed at high elevation. This is not necessary with the JXIQ heater because it has a special venturi-type combustion system which self-compensates for changes in barometric pressure. Air flow through the blower inlet pulls the correct flow of gas into the burner regardless of air density. JXIQ heaters are CSA certified for elevations of up to 4,500 feet above sea level. At elevations above 4,500 ft., the heater BTU output can be expected to be reduced by 4% for every 1,000 feet over 4,500 feet above sea level.	
	LIQUID PROPANE (LP)		

* Indoor installation is not recommended for liquid propane heaters.

**Adjustable water pressure switch factory set to 7 psi.

See Section 5.4, Water Pressure Switch Adjustment for adjustment instructions.

Review Special Precautions for liquid propane heaters (see Section 4.3, Special Precautions for LP Gas).

†For gas pipe size requirements see Section 4, Gas Connections.

‡Value displayed is for operating (fired) pressure not static.

§ Use type B double-wall gas vent, per table 13.1(a) NFPA 54C.

Any changes to the heater, gas controls, gas valve, air orifice, gas orifices, wiring, or improper installation may void the warranty. If change is required to any of the above, contact your local Jandy distributor, visit www.jandy.com or call technical support at 1.800.622.7933.

1.5 Dimensions




Figure 1. General Dimensions

For ASME compliant heater models JXIQ400NC, JXIQ400PC, JXIQ260NC, JXIQ260PC, JXIQ400NS, JXIQ400PS, JXIQ260NS, and JXIQ260PS please see Section 14, Appendix A, ASME® Compliant Header.

1.6 Certification Codes and Standards

	USA	CANADA
Design Certified	CSA (Canadian Standards Association)	
Compliant	ANSI® Z21.56 California South Coast Air Quality Management District's (SCAQMD) Rule 1146.2	CSA 4.7
National Codes	National Fuel Gas Code	Natural Gas and Propane Installation Code
	NFPA® 54/ANSI Z223.1	CAN/CSA-B149.1
	Pay particular attention to the chapter addressing Venting of Equipment.	Minimum combustion air requirements MUST be followed for proper and safe operation. Failures may occur when only the minimum combustion air openings are used.

All Jandy heaters must be installed in accordance with the local building and installation codes as per the utility or Authority Having Jurisdiction (AHJ). In the absence of local codes, please refer to the latest edition of the National Fuel Gas Code, ANSI Z223.1/NFPA54, and/or Natural Gas and Propane Installation Code, CSA B149.1. JXIQ pool and spa heaters meet or exceed the requirements of energy conservation regulations such as those in states that have disallowed the use of continuously lit pilot type ignition sources.

FCC Regulatory Compliance Statement

This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions:

- (1) This device may not cause harmful interference, and
- (2) this device must accept any interference received, including interference that may cause undesired operation.

This device must be installed to provide a separation distance of at least 20 cm from all persons and must not be collocated or operating in conjunction with any other antenna or transmitter, except in accordance with FCC multi-transmitter product guidelines.

⚠ CAUTION

Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

NOTE: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

ISED Canada Regulatory Compliance Statement


This device contains license-exempt transmitter(s)/receiver(s) that comply with Innovation, Science and Economic Development Canada's license-exempt RSS(s). Operation is subject to the following two conditions:

1. This device may not cause interference.
2. This device must accept any interference, including interference that may cause undesired operation of the device.

1.7 Heater Components

⚠ WARNING

Never bypass, disconnect, or render inoperable the flue temperature sensor, high limit switches, water temperature sensors, water pressure switch, gas pressure switch and air pressure switches. Doing so may result in property damage, serious injury or even death, including but not limited to from carbon monoxide poisoning.



 Indicates a safety control equipped to protect internal components and extend the life of the heater.

- a.  **Flue Temperature Sensor:** Monitors temperature at the exhaust flue. If excessive temperatures are detected, (> 464°), a fault will be displayed, combustion will stop and heater will shutdown for a minimum of 10 minutes then will auto restart. If there are 3 successive failures in a 60 minute period the heater will go into a latching or hard lockout.
- b. **Hot Surface Igniter:** When current is passed through the ceramic material of the igniter it will achieve temperatures great enough to initiate combustion of the air/fuel mixture. After ignition, the hot surface igniter confirm flames through rectification.

- c.  **Ignition Control:** Provides energy for ignition, monitors flame quality and controls the gas valve. Upon call for heat, the blower is activated to purge the combustion chamber. Electrical power is then applied to the hot surface igniter. When ignition temperature is attained, the gas valve opens and ignition occurs. If stable flame is detected the igniter will power down. If stable flame is not detected the control system will close the valve to prevent further gas release. If a total of 3 ignition attempts fail an ignition fault is displayed and the heater will go into a latching or hard lockout.
- d.  **Sacrificial Anode:** Provides protection against galvanic corrosion and stray current that can otherwise attack and reduce the life of internal components such as the heat exchanger tubes.
- e.  **High Limit Switches:** Prevent water of excessive temperatures from being discharged from the heater. If either switch, one at the heat exchanger first pass 135°F (57°C) and one at the heat exchanger outlet 150°F (65°C), senses excessive temperature, the gas valve will close and combustion will stop.
- f.  **Heat Exchanger Outlet Temperature Sensor:** Dual purpose sensor that serves as a drain plug and an outlet temperature sensor which measures the temp rise (delta T, the difference between the inlet water temp and the outlet water temp) of the heat exchanger outlet. If the delta T exceeds the lower or the upper limit, it will log a fault code of either Temp Rise High or Temp Rise Low, accordingly.
- g.  **Pool/Spa Inlet Water Temperature Control:** Senses water temperature by means of a thermistor. Heater will operate to attain and maintain the water temperature according to the heater settings. Two separate thermostat settings are supported, typically used to set pool and spa temperatures.
- h.  **Water Pressure Switch:** Senses whether or not water is available to the heater by measuring back pressure at the header inlet. If insufficient pressure is detected, the display will indicate a "Check Flow" fault and combustion will stop.
- i.  **Gas Pressure Switch:** Monitors incoming gas supply pressure. If the static pressure drops too low, it will prevent the heater from firing. While the heater is firing, if the dynamic pressure remains low for too long, it will also shutdown the heater and the display will indicate a Low Gas Pressure fault code "LOW GAS SUPPLY PRESSURE".
- j. **Gas Valve:** Controls gas flow into the burner. Enables flow when the temperature control calls for heat and all safety controls enable operation. It also regulates gas pressure to ~0.2" WC (Water Column) below the air pressure at the blower inlet. Necessary pressure regulation cannot be accomplished with common (positive pressure) gas valves.
- k. **Combustion Blower and Air Orifice:** Draws in air and fuel gas creating an air/fuel mixture that is passed through the burner for combustion. The fan will operate for several seconds before flame initiation and after the flame is extinguished to purge the combustion chamber for a clean burn and to expel any residual exhaust gas.
- l.  **Air Pressure Switch:** Monitors the vacuum (negative pressure) within the blower housing. This switch verifies that air is flowing through the combustion system by sensing pressure. If air flow is inadequate, combustion will stop and a fault will be displayed.

Section 2. Getting Started

Install the JXIQ in accordance with the procedures in this manual, local codes and ordinances, and in accordance with the latest edition of the appropriate national code. See Section 1.6, *Certification Codes and Standards*.

If the heater is to be operated in below freezing conditions it should be installed in a protected outdoor shelter. See Section 3.3, *Indoor and Outdoor Shelter Installation*.

All gas-fired products require correct installation to ensure safe operation. The requirements for pool heaters include the following:

- Field assembly (if required)
- Appropriate site location, clearances and flooring
- Sufficient combustion and ventilation air
- Properly sized gas meter and piping
- Proper electrical wiring
- Sufficient water flow

This manual provides the information needed to meet these requirements. Review all applications and installation procedures before continuing the installation.


2.1 Package Contents

For ASME compliant heater models JXIQ400NC, JXIQ400PC, JXIQ260NC, JXIQ260PC, JXIQ400NS, JXIQ400PS, JXIQ260NS, and JXIQ260PS please see *Section 14, Appendix A. ASME® Compliant Header*.

Before completely unpacking the unit please inspect carton for damage. In addition, please check the carton label to ensure that you have the correct fuel type and BTU rating for your application.



OR



Item	Description	Qty.
1	JXIQ Heater	1
2	Versa Plumb® Sweep Elbow	1
3	2 in Universal Union Tailpiece	2
4	2 in Universal Union Cap	1
5	2 in Universal Union O-ring	3
6	2 in Universal Union Nut	3

2.2 Required Equipment

Please ensure that the following equipment is available to the installer at the time of installation.

2.2.1 Tools



Safety Eyewear



Gloves



Phillips Screwdriver



Flathead Screwdriver



Pipe Wrench



Adjustable Wrench



3/16 in Hex Key



Channel Locks

Digital Differential
Manometer

Voltage Meter



PVC Pipe Cutter



Power Drill



Tape Measure

2.2.2 Materials Supplied by Installer

Please ensure that all materials used during the installation are in accordance with local codes or the authority having jurisdiction (AHJ) requirements. If you have any questions regarding the materials that need to be used during this installation please call the Zodiac customer service center at 1.800.822.7933.

Indoor installations will require additional venting and exhaust conversion materials which are outlined in detail in *Section 3.3, Indoor and Outdoor Shelter Installation*.

NOTE: Required materials may differ from the materials listed. Be sure to confirm with all local and national codes before beginning the installation.

Gas Supplies	Electrical Supplies	Plumbing Supplies
Appropriately sized Gas Piping (see Section 4.1, Supply Gas Requirements)	120 or 240 VAC	PVC Piping
Manual Gas Shut Off Valve	Conduit Elbow/Conduit connector	PVC Cement
Gas Union	Flexible Conduit	PTFE (Teflon™) Tape
Gas Pipe Cap	Wire Nuts (3 ea.)	
Leak Solution		
1/16 in Hose "T"		
1/8 in - 1/16 in Barbed Adapter		
1/16 in Flexible Hose		

Section 3. Location Requirements

The JXIQ heater is shipped from the factory with an exhaust vent configured for outdoor installation. The heater is also design-certified for indoor installations; see Section 3.3, *Indoor and Outdoor Shelter Installation* for details. In Canada indoor installation must use a two pipe direct vent (combustion air and vent piping) see Section 3.3.2, *Direct Air Intake* & Section 3.3.3, *Exterior Venting And Air Intake* for details.

Location of the heater below or above the pool water level affects operation of its water pressure switch. See Section 5.4, *Water Pressure Switch Adjustment* for more information.

Equipment must be installed on a firm, solid, non-absorbent level surface; and per the requirements of local codes and Authority Having Jurisdiction (AHJ). Equipment can weigh up to 156 lbs. (57 kg). Use suitably rated mounting surface materials to avoid risk of settlement, and never use sand to level the equipment as the sand will wash away. Check local building codes for additional requirements.

NOTE: If the heater is to be operated in below freezing conditions it should be installed in a protected outdoor shelter.

CAUTION

When pool equipment is located below the pool surface, a leak from any component can cause large scale water loss or flooding.

Zodiac Pool Systems LLC is not responsible for such water loss or flooding or resulting damage.

3.1 Clearances

The heater must be installed in a location that allows clearances for maintenance and inspection. Minimum distances from combustible surfaces must also be maintained. All criteria given in the following sections reflect minimum clearances as stated in the national standards. However, each installation must also be evaluated, taking into account prevailing local conditions such as wind speed and direction, proximity and height of obstructions that may block ventilation, and proximity to public access areas.

Service Clearance

- 36 inches (92 cm) from top of heater for removal of top panel.
- 18 inches in the US and 24 inches (61 cm) in Canada from the front panel of the heater.

NOTE: One exception to this is if the top panel is reversed such that the water plumbing is now on the left hand side of the heater and the exhaust is on the right hand side. In this case, you will need the service clearance (18" US/24" Can) from the rear panel of the heater.

Combustible Surfaces

WARNING

Improper clearances or installation on carpet can lead to a fire and result in property damages, severe injury, or even death.

Each heater face requires a 6 inch (15 cm) clearance from combustible surfaces. Although it is not advisable, the heater base can be placed on a combustible surface for operation. However, **do not install the heater on carpet.**




Figure 2. Clearances

3.2 Outdoor Installation

Locate the heater:

- On a level solid surface.
- 5 ft (1.5 m) from inner pool edge unless separated by a permanent solid barrier, i.e. a wall or fence.
- Away from doors windows or louvers that connect in any way to occupied or inhabited areas of the building.

NOTE: In Canada the top of the exhaust vent must be at least 10 feet (3 m) from any building opening.

- Away from rainwater runoff.
- This heater is approved for use outdoors without additional venting attachments. If there are concerns over extreme weather conditions, we do provide the option to add up to 25 feet (7.5 m) of Category III venting material with an approved vent termination cap. See Section 3.3, *Indoor and Outdoor Shelter Installation* for details on outdoor venting.
- Away from potential sprinkler water intrusion.
- So that the top of the heater is at least 3 feet (1 m) below any overhang.
- So that the top surface of the heater is at least 3 feet (1 m) above any forced air inlet within 10 feet (3 m).
- In an open area, not under a deck or other structure, unless the installation is treated as an indoor installation under a deck or other structure with adequate clearance to combustibles, clearance for servicing, and proper venting. Installation must be fully in accordance with the "Indoor and Outdoor Shelter Installation" (Section 3.3, *Indoor and*

Outdoor Shelter Installation) and "Direct Venting/Direct Air Intake" (Section 3.3.2, *Direct Air Intake & Section 3.3.3, Exterior Venting And Air Intake*) requirements of this manual, as well as the National Fuel Gas Code NFPA® 54 / ANSI® Z223.1 or the Canadian Natural Gas and Propane Installation Code CAN/CSA-B149.1 in Canada.

Venting must be terminated in a location that guarantees proper exhaust venting and is not at risk of blockage from leaves, pine-needles, snow, dirt, debris, and any other combustible and non-combustible materials.

In addition, the heater must be installed with "Direct Venting/Direct Air Intake" (Section 3.3.2, *Direct Air Intake & Section 3.3.3, Exterior Venting And Air Intake*) in accordance with this manual. Direct air intake must be located to guarantee uninterrupted opening to outside air for combustion and ventilation, and not at risk of blockage from leaves, pine-needles, snow, dirt, debris, and any other combustible and non-combustible materials.

Some local installation codes may have requirements that exceed those of the installation manual and national codes. The heater must be installed by a licensed professional in accordance with the codes being enforced by the Local Authority Having Jurisdiction (AHJ) or competent authority in Canada.

If it is unclear that all installation requirements have been properly satisfied, seek the assistance of a Registered Professional Engineer.




Figure 3. Location Requirements

⚠ WARNING

United States

Do not install the heater with the top of the vent assembly within 4 feet (1.22 m) horizontally, 4 feet (1.22 m) below or less than 1 ft (300 mm) above of any opening into a building. Local codes and installation requirements may vary.

Canada



Do not install the heater with the top of the vent assembly within 10 feet (3.0 m) of any opening into a building. Local codes and installation requirements may vary.

3.2.1 Anchor Bracket Installation


Anchor brackets do not come standard with the JXIQ. If you require the anchor brackets for your installation please order kit #R0593400.

Anchor brackets should be installed in any circumstance where the heater may be subject to natural risks such as extreme weather or earthquake. In Florida, the heater is required to be securely fastened to the equipment pad to meet the applicable requirements of the Florida Building Code. Other jurisdictions may have similar requirements for extreme weather or other natural hazards. Check your local codes for details.


- Using an adjustable wrench or equivalent tool loosen (DO NOT REMOVE) the retaining nut on the bracket. The upper and lower anchor bracket should be able to rotate freely about the retaining pin.
- Slide the bracket into the slot located at the lower corner of the heater base.



- Rotate lower anchor bracket into final position. Ensure that the lower anchor bracket is flush with the equipment pad surface and level.
- Tighten the retaining nut so that the anchor bracket assembly is secure.



- Drill a hole in the concrete using the lower anchor bracket hole as a guide. It is advised that a hammer drill with an appropriate concrete drill bit be used.
- Place a screw in the hole and tighten to fasten the anchor bracket to the concrete pad. **Do not over torque the screws.**



NOTE: Depending on the location of and access to the bracket, it may be necessary to mark the drill location using the lower anchor bracket hole as a guide. Remove the bracket from the heater, drill the hole and then reattach the bracket to the heater base.

Concrete screws are not provided in the anchor bracket kit. Use size 1/4 in x 2-1/4 in galvanized or plated concrete screws and washers.

3.3 Indoor and Outdoor Shelter Installation

Due to the higher risks and hazards of liquid propane (LP) gas, Zodiac Pool System LLC does not encourage installation of LP gas heaters indoors; refer to Section 4.3, *Special Precautions for LP Gas*.

The heater is CSA design-certified for indoor installations. In Canada indoor installation must use a two pipe direct vent (combustion air and vent piping) see Section 3.3.2, *Direct Air Intake* and Section 3.3.3, *Exterior Venting And Air Intake* for details. Please keep in mind the service and combustible surface clearances from Section 3.1, *Clearances* when

selecting an installation location. You will also need to make considerations for intake combustion air see Section 3.3.1, *Combustion Intake Air Supply* and exhaust venting see Section 3.3.4, *Exhaust Venting*. In addition, when pool equipment is installed indoors, appropriate containment measures and drains should be considered for the prevention of property damage in the event of a water leak.

NOTE: An outdoor shelter is an unoccupied enclosure which does not communicate directly with occupied areas. If the outdoor shelter is a completely closed structure, air openings in accordance with the size recommendations described in Section 3.3.1, *Combustion Intake Air Supply* must be maintained. If the structure does not have outside air openings then air must be provided for combustion by using our fresh air vent kit.

3.3.1 Combustion Intake Air Supply

As outlined in the latest edition of ANSI® standard Z223.1 (NFPA® 54), the heater location must be properly vented to provide sufficient air supply for proper combustion.

When combustion air is supplied directly through an outside wall, each opening should have a minimum free area of 1 square inch per 4,000 BTU/h (1.2 kW) input of the total input rating of all appliances in the enclosed area. If combustion air must pass through horizontal ducts, each opening should have a minimum free area of 1 square inch per 2,000 BTU/h (1.2 kW) input of the total input rating of all appliances in the enclosed area. Details can be found in Figure 4.

The "Minimum Net Free Open Area" information from Figure 4 is not applicable in installations where exhaust fans or blowers of any type are used. Any equipment which exhausts air from the room where the heater is installed can deplete the combustion air supply which could lead to poor combustion, decreased heater efficiency and reliability and increased emissions. This could cause flue products to accumulate in the room. Additional air must be supplied to compensate for such exhaust. Consult a professional engineer to ensure that installations where exhaust fans or blowers are used are designed and installed in accordance with all applicable local and national installation codes.

In addition, the heater must be completely isolated and protected from any source of corrosive chemical fumes or corrosive vapors (i.e., chlorine or hydrochloric acid).

⚠ WARNING

Do not store any chemicals, cleaners, or other corrosive material near combustion air openings or in the room. Avoid locating appliance vents in the vicinity of combustion air openings. Failure to prevent corrosive materials from mixing with combustion air can result in reduced heater life and unsafe heater operation.


3.3.2 Direct Air Intake

In certain applications it may be necessary to supply intake air directly to the heater. You will need to order and install the direct air conversion R-Kit R0724600.


A total equivalent length of 65 ft (20 m) of 3 in (75 mm) PVC tubing, 6 in (152 mm) PCV tubing for JX1400 399,000 BTU models, can be used to bring the intake air directly to the blower input. Please be aware that each elbow used will account for 12 ft (3.6 m) of length. For ease of access, remove the rear and top panels.

TIP: When removing the air hoses from the air orifice, mark the hoses with tape or a marker to help with reassembly.

- Loosen the two screws securing the air orifice and screen in place. Remove the air pressure switch and gas valve hose from the air orifice.
- Remove the air orifice, separate and dispose of the orifice screen.



- Align the orifice adapter with the orifice tabs and secure with four screws.
- Dry fit the 3 in (75 mm) PVC tubing, or 6 in (152 mm), PVC Tubing for JX1400 399,000 BTU models, into the orifice adapter. Mark screw hole locations with a pen. Remove and drill pilot holes in the PVC. Fit the PVC into the orifice adapter, align the holes and secure with four screws.
- Reinstall the air orifice and air hoses.
- Install the new rear panel over the PVC and secure with four screws.






Figure 4. Indoor and Outdoor Shelter Installation

3.3.3 Exterior Venting And Air Intake

The JXIQ must be vented to the outdoors. It must not be vented in common with any other appliance, even if that appliance is of the condensing type. Common venting can result in severe corrosion of the JXIQ or of the other appliances or their venting, or escape of combustion product gases through such appliances or vents. Do not vent the JXIQ to a fireplace chimney or building chase.

Combustion air ducting, when provided, must not be shared with any other appliance or with another JXIQ. Doing so may result in flow of air through the other appliances instead of directly from the outdoors.

The combustion air intake and vent outlet must be located exterior to the building and in the same pressure zone - i.e. both through the roof or both through a side wall. The vent terminal must be located in accordance with local codes, as applicable, and in accordance with the following:

- Locate the vent terminal so that it will not be damaged by pedestrians and other traffic, and so that the discharge is not offensive. The National Fuel Gas Code requires a through-wall vent terminal be at least 7 feet (2.13 m) above grade if located at a public walkway.
- Locate the vent terminal so the vent exhaust does not settle on building surfaces and other nearby objects. Vent products may corrode such surfaces or objects.
- Locate the vent terminal at a sufficient horizontal distance from any gas or electric metering, regulating or relief equipment. In the United States, this distance must be at least 4 feet (1.22 m). In Canada, it must be at least 10 feet (3.05 m).
- Locate the vent terminal at a sufficient horizontal distance from any building opening. Take special care to assure that combustion products do not enter a building through windows, doors, ventilation inlets, etc. In the United States, this distance must be at least 4 feet (1.21 m). In Canada, it must be at least 10 feet (3.04 m).

As shown in Figure 5 and Figure 6 the combustion air intake and the vent outlet must be installed no closer together than 18 in (45.7 cm) and no farther apart than 60 in (1.5 m). The combustion air inlet opening must face downward to prevent entry of rain or snow. The vent outlet must discharge away from the combustion air inlet - normally in a horizontal direction when on a wall and vertically upward when on a roof. Both should terminate at least 12 in (30.5 cm) above the snow accumulation level. In locations with freezing climate, extension of the vent pipe outside of the building should be minimized.




Figure 5. Vent and Combustion Air Terminals at Exterior Wall

- Connect the vent pipe to the heater vent collar with an air-tight corrosion-resistant clamp. The connection must not allow leakage of combustion products into the space but should be removable for service.
- Install vent piping with a continuous rise of at least 1/4 in per foot (20 mm per meter) away from the heater. This will assure that any condensate forming in the vent pipe will flow back to the heater where it can be disposed of properly.
- Support vent piping with suitable hangers so its weight does not bear on the heater or building penetration and so that piping joints are not strained. Support horizontal runs at intervals no greater than 6 feet (1.82 meters), and closer if necessary to avoid sagging. Sagging can trap condensate water and block the vent.

NOTE: Both combustion air and vent piping joints must be sealed appropriately. Connection of combustion air and vent piping to the heater should be serviceable - i.e. removable for heater service.




Figure 6. Vent and Combustion Air Terminals at Roof

3.3.4 Exhaust Venting

When the JXIQ heater is installed indoors (US ONLY) or in an outdoor shelter it can be vented as a Category I or Category III appliance. In either case, the vent pipe sizing must be in accordance with the specifications listed in Table 1. Category III is required for indoor installation in Canada.

For cases when the heater is installed outdoors and there is concern over extreme weather conditions, we also provide the option of adding Category III venting per the specifications listed in Table 1.

It is recommended that all venting be engineered by a licensed mechanical contractor.

- **Category I:** Appliance operates with a negative vent static pressure, a vent gas temperature that avoids excessive condensate production and will vent vertically terminating at the roof. Venting materials for Category I must be Type B double wall vent. Category I is not approved for indoor installation in Canada.
- **Category III:** Appliance operates with a positive vent static pressure, a vent gas temperature that avoids excessive condensate production and can be vented horizontally terminating at a side wall.
- **Do not** terminate heater vents near air conditioning or air supply fans which could pick up exhaust flue products, such as carbon monoxide and other hazardous effluent, and return them inside the building.
- Vent pipe type and material must be carefully selected and depends on the type of installation.
- **Do not** locate the vent terminal where exhaust flue products could strike against building materials and cause degradation.
- Vent opening should be well away from landscaping or other obstructions that would prevent free air flow to and from vent terminal.
- **Do not** terminate vent under decks, stairs, or car ports.
- **Do not** use the appliance to support the vent pipe.
- Vent piping must be supported with no low spots or sagging which could allow condensate to collect.
- Horizontal runs must be sloped upwards away from the heater to a vent terminal at a minimum of 1/4 in per horizontal foot (2 cm/m). See Figure 4.
- Install the vent pipe so it can expand and contract freely with temperature changes.
- **Do not** run the heater vent into a common vent with any other appliance.
- It is recommended that vent runs over 18 feet be insulated to reduce condensation and use a condensate trap in the vent run close to the heater, especially in cold climate installations.
- When using Category III vent material, it is acceptable to use a larger diameter pipe size if needed. ‡
- For heaters installed outdoors where there is concern over extreme weather conditions, Category III venting with approved vent termination cap can be installed as noted in Table 1 and Section 3.3.7, *Outdoor Heater Install with Venting for Extreme Weather Conditions*. ‡

IT IS RECOMMENDED THAT ALL VENTING BE ENGINEERED BY A LICENSED MECHANICAL CONTRACTOR

Codes*	 US	National Fuel Gas code ANSI® Z223.1 (NFPA® 54)					
	 CA	CAN/CSA-B149.1					
Category	Static Press.	Stack Temp.	Condensate	Termination Location	Pipe Sizing		
					Model	Pipe Size	Special Gas Vent Length† (Vertical or horizontal)
I	Negative	High	Minimal	Roof	200	6 in (15 cm)	N/A
					260	7 in (18 cm)	N/A
					400	8 in (20 cm)	N/A
II	Positive	High	Minimal	Roof or Side Wall	200	4 in (10 cm) or larger	65 ft (20 m)
					260	4 in (10 cm) or larger	65 ft (20 m)
					400	4 in (10 cm) or larger	65 ft (20 m)
III	Positive	High	Minimal	Outdoor‡	200	4 in (10 cm) or larger	25 ft (7.5 m)
					260	4 in (10 cm) or larger	25 ft (7.5 m)
					400	4 in (10 cm) or larger	25 ft (7.5 m)

*Ensure that you are referencing the latest edition and pay special attention to the chapter addressing "Venting of Equipment".
†For each elbow installed, reduce the run length by 12 feet (3.7 m)
‡Applies to outdoor installed heater with concerns over extreme weather conditions.

Table 1. Vent Pipe Sizing Requirements

⚠ WARNING

Vent pipe materials, sizing, and installation must be as required by the National Fuel Gas Code NFPA 54/ ANSI® Z223.1 or the Canadian Installation Codes for Gas Appliances CAN/CSA-B149.1. Undersized pipe can result in inadequate venting and oversize pipe can result in vent condensation. Improper selection of vent pipe material, incorrect sizing of the pipe, and incorrect installation of vent piping can result in release of combustion products to the indoors. This can cause serious injury or death by Carbon Monoxide poisoning or asphyxiation.


⚠ WARNING

Improper installation or maintenance can cause nausea or asphyxiation from carbon monoxide in flue gases which could result in severe injury or death. For indoor installations, as an added measure of safety, Zodiac Pool Systems LLC strongly recommends installation of suitable carbon monoxide detectors in the vicinity of this appliance and in any adjacent occupied spaces. Incorrect design and installation of heater vents and ducts can result in personal injury, damage to property, or death. To avoid such hazards, the heater must be installed only by a qualified professional service technician.


3.3.5 Indoor and Outdoor Shelter Exhaust Conversion

For both Category I and Category III vent types the heater must first be converted to an indoor exhaust type. In order to complete the conversion you will need to order exhaust conversion R-Kit R0731100.

- Remove two screws securing the exhaust grill to the exhaust grill backplate.



- b. Remove exhaust grill.
- c. Remove the two screws securing the rain shield to the exhaust backplate.
- d. Remove the rain shield.
- e. Remove the remaining two screws securing the exhaust backplate to the exhaust outlet.
- f. Remove the exhaust grill backplate.



- g. Using two #10 thread cutting screws secure the vent adapter from R-Kit R0731100 to the exhaust outlet.
- h. If venting for Category I, install an appropriate vent pipe increaser to accommodate the correct pipe size from Table 1. Secure to the vent adapter using the screw clamp.


When the installation requires horizontal venting in excess of what is allowed for Category I installations or calls for horizontal discharge, the JXIQ may be installed with a Category III venting system.

Vent the heater either vertically or horizontally using A129-4C stainless steel components. Consult manufacturers such as Z-Flex® or Heat Fab® to obtain approved components. Venting materials must comply with UL® 1738 for Category III, Special Gas Vent. Based on the normally expected flue temperatures of this appliance, **PLASTIC VENTING MUST NOT BE USED.**

- i. If venting for Category III, install appropriate vent pipe from Table 1. Secure to the vent adapter using the screw clamp to ensure a proper seal.

Double check that there are no possible leak paths between joints. If a leak path is identified or suspected it can be sealed using red RTV 600°F rated silicone adhesive.

When using parts or materials from other manufacturers please be sure to follow the manufacturers instructions completely to ensure harmonious function.



IMPORTANT

In the Commonwealth of Massachusetts, additional requirements, covered in document CMR 248 5.00, which supersede some of the requirements of ANSI Z223.1 (NFPA 54) apply to Side Wall Horizontally Vented appliances. If installing this product using an approved side-wall horizontal vent system in the Commonwealth of Massachusetts, be sure to adhere to these additional requirements. These requirements include verbiage that says that the property owner is to ensure that Carbon Monoxide Detectors are installed in the vicinity of the appliance and also on all levels of the dwelling in which the appliance is installed.

For further instructions, contact Technical Support at 1.800.822.7933.

3.3.6 Indoor and Outdoor Shelter Exhaust Termination

Category I: Appliance must be vented vertically and terminate at the roof. Vent must terminate at least 2 feet (610 mm) above any objects within 10 feet (3.05 m). Termination must pass through a properly installed and approved roof jack, a properly sized storm collar and an listed vent cap. See Figure 4.

Category III: Appliance can be vented vertically to terminate at the roof or vented horizontally to terminate at a side wall. Side wall vents must be installed and located in accordance with the National Fuel Gas Code NFPA® 54 / ANSI® Z223.1 or the Canadian Natural Gas and Propane Installation Code CAN/CSA-B149.1. In addition some local installation codes may have requirements that exceed those of the national codes. The product must be installed in accordance with the codes being enforced by the local Authority Having Jurisdiction (AHJ).




Figure 7. Side Wall Vent Termination

3.3.7 Outdoor Heater Install with Venting for Extreme Weather Conditions

In the event that the heater is installed outdoors and there are concerns over extreme weather conditions, the heater exhaust can be converted using Category III vent material as shown in this section. An approved Category III vent termination cap needs to be installed vertically. We recommend using a vent termination cap from Z-Flex (part #: 2SVSRCF04). The vent adapter is also required and can be ordered as R-Kit R0731100. This heater is approved for use outdoors without additional venting attachments. If there are concerns over extreme weather conditions, we do provide the option to add up to 25 feet (7.5 m) of Category III venting material with an approved vent termination cap.

- Remove two screws securing the exhaust grill to the exhaust grill backplate.
- Remove exhaust grill.
- Remove the two screws securing the rain shield to the exhaust backplate.
- Remove the rain shield.
- Remove the remaining two screws securing the exhaust backplate to the exhaust outlet.
- Remove the exhaust grill backplate.
- Using two #10 thread cutting screws secure the vent adapter from R-Kit R0731100 to the exhaust outlet.
- Install 4" elbow to the vent adapter using the screw clamp to ensure a proper seal.

Vent the heater vertically using A129-4C stainless steel components. Consult manufacturers such as Z-Flex® or Heat Fab® to obtain approved components. Venting materials must comply

with UL® 1738 for Category III, Special Gas Vent. Based on the normally expected flue temperatures of this appliance, PLASTIC VENTING MUST NOT BE USED.


- i. Install vent cap to the vent elbow. Double check that there are no possible leak paths between joints. If a leak path is identified or suspected it can be sealed using red RTV 600°F rated silicone adhesive.

When using parts or materials from other manufacturers please be sure to follow the manufacturers instructions completely to ensure harmonious function.

IMPORTANT

In the Commonwealth of Massachusetts, additional requirements, covered in document CMR 248 5.00, which supersede some of the requirements of ANSI Z223.1 (NFPA 54) apply to Side Wall Horizontally Vented appliances. If installing this product using an approved side-wall horizontal vent system in the Commonwealth of Massachusetts, be sure to adhere to these additional requirements. These requirements include verbiage that says that the property owner is to ensure that Carbon Monoxide Detectors are installed in the vicinity of the appliance and also on all levels of the dwelling in which the appliance is installed.

For further instructions, contact Technical Support at 1.800.822.7933.



3.3.8 Precautions Against Common Venting

Zodiac Pool Systems LLC does not recommend using a common vent to vent multiple appliances through a common duct. If no other option is deemed available by the installer, seek the assistance of a Registered Professional Engineer for proper design of a common venting system.

A properly designed common venting system must include vent temperature limit switches for each appliance. All vent limit switches must be wired in series so as to prevent any appliance from firing in the event of a blocked vent. An outside draft inducer must be installed to pull and create negative pressure in the vent system. Refer to ANSI® Z223.1 or in Canada CAN/CSA B149.1 for more information on common venting multiple appliances. **Do not** connect vent systems of different categories to the same venting system.

3.3.9 Inspection and Replacement of Existing Vent System with New Components

When replacing an existing pool heater with the JXIQ, it is recommended that a new appropriate venting system is installed with the new heater. However, if the existing venting system must be used, be sure to carefully inspect the existing system to ensure that it is in good condition and appropriate for the JXIQ heater. Replace any parts that are not in serviceable condition before completing the installation.

Section 4. Gas Connections

Gas piping installation must be in accordance with the latest edition of ANSI Z223.1 and all local codes. In Canada, the installation must be in accordance with CAN/CSA B149.1 and all local codes that apply.

The heater must be isolated from the gas supply piping system by closing the individual manual shut off valve during any pressure testing of the gas supply piping system at test pressure greater than or equal to 1/2 psi (3.5kPa).

⚠ CAUTION

Permanent damage to the gas valve will occur if the installation procedures are not followed correctly.

⚠ WARNING

The JXIQ pool and spa heaters are designed for use with either natural gas or LP gas. Check the rating plate on the front of the combustion chamber to be sure that the heater is designed to use the type of gas being supplied. **CONVERTING THIS HEATER FOR USE WITH ANY OTHER FUEL TYPE IS NOT RECOMMENDED BUT, WHEN NECESSARY, SHOULD ONLY BE PERFORMED BY A LICENSED AND QUALIFIED PROFESSIONAL, AND ONLY AFTER CONTACTING ZODIAC POOL SYSTEMS LLC FOR THE PROPER INSTRUCTIONS AND CONVERSION KIT.**

All questions should be directed to the Zodiac customer service center at 1.800.822.7933.

- Refer to table for correct gas inlet piping length from the gas meter to the heater.
- Check the gas meter to make sure it will supply enough gas to the heater and any other appliances using the same gas supply. If unsure, contact your local gas utility to confirm.
- Install a manual gas shutoff valve outside the heater body for service and safety. Never install the shutoff valve inside the body of the heater.
- Install a sediment trap and union ahead of the gas controls and outside the heater body. See Figure 8.
- Do not use a restrictive gas valve.

NOTE: Check supply pressure and local code requirements before proceeding with installation.

Consider pipe fittings when determining gas pipe sizing. For every elbow used add three (3) feet to straight pipe length.

Table 2 shows the minimum supply gas pipe size required. Larger pipe size can be used if required by local code or if desired.

It is critical that the incoming gas supply pressure at the heater is within the maximum and minimum pressure requirements. If the range of acceptable supply pressure is not provided, the gas supply system to the heater must be modified to meet pressure requirements.

4.1 Supply Gas Requirements

Maximum Equivalent Pipe Length (Sch 40 Metallic Pipe)								
Natural Gas 1000BTU/FT ³ — 0.60 Specific Gravity @ 0.5 in. W.C. Pressure Drop								
Propane Gas 2500BTU/FT ³ — 1.53 Specific Gravity @ 0.5 in. W.C. Pressure Drop								
	3/4"		1"		1-1/4"		1-1/2"	
Model	NG	LP	NG	LP	NG	LP	NG	LP
JXIQ200	25 ft	60 ft	90 ft	215 ft	360 ft			
JXIQ260	15 ft	35 ft	50 ft	125 ft	210 ft	480 ft	445 ft	
JXIQ400	*	15 ft	20 ft	55 ft	95 ft	225 ft	215 ft	480 ft

* A 3/4" gas line can be used for up to 5 feet maximum length from the gas valve in addition to the sediment trap.

Table 2. Natural Gas Pipe Size Requirements

ATTENTION

Do not use flexible appliance connectors on any gas connections unless the connector is CSA approved for outdoor installation, and is marked with the BTUH capacity (which must be equal to or greater than the heater rated input) and the type of gas (Natural or LP). Also, any flexible connectors, such as CSST buried underground must be certified for underground installation and meet all applicable codes. Please note, use of flexible connector still requires the installation of a sediment trap per NFPA 54. See Figure 8.

NOTE: The gas line from the meter is usually larger than the gas valve. Therefore, you will need to reduce connecting pipe as necessary. Make this reduction as close to the heater as possible.




Figure 8. Manual Shut-off Valve and Sediment Trap

4.2 Inlet Gas Pressure Test

Before operating the heater it is necessary to test the input gas pressure to ensure that it falls within the required range as outlined in Table 3.




NOTE: The heater is equipped with a gas supply pressure switch that will open and prevent the heater from firing, or shutdown the heater during operation, if the supply pressure is too low. Proper inlet gas pressure is required for safe and reliable operation of the heater. When the gas supply pressure switch opens, inadequate gas delivery systems are typically upgraded by the utility at no charge to homeowners.

Inlet Gas Pressure	NG (Natural Gas)	LP (Liquid Propane)
	Inches W.C.	
MAX	10.5	14
MIN	4	4

- All readings must be made while heater is operating.
- Relying on any reading taken while heater is off may result in poor performance and difficulty in operation.

Table 3. Supply Gas Input Pressure Requirements

- Pull gas inlet grommet away from heater body panel.
- Remove one screw and the gas valve access panel.
- Remove 1/8 in NPT plug using a 3/16 in hex key.
- Install a 1/8 in to 1/16 in barbed adapter.
- Connect positive manometer lead to barbed adapter.



- Inlet gas pressure must be taken while the heater, and if possible, all other gas burning appliances supplied by the same gas delivery system, are operating.

- If the gas supply pressure is less than required, check for an undersized pipe between the meter and the heater, a restrictive fitting, or an undersized gas meter. If needed contact the local gas utility company for assistance.
- Once proper inlet pressure has been confirmed, shut off gas supply.
- Remove manometer, hose and barbed fitting from the gas valve.
- Apply Natural Gas/Propane approved sealant to the NPT plug and reinstall.
- Before operating the heater, test the gas supply system and all connections for leaks using a soap solution. **Do not use an open flame to test for leaks.**
- Reinstall the gas valve access panel.
- Secure the gas inlet grommet at heater side panel.

4.3 Special Precautions for LP Gas

Under the same environmental conditions, liquid propane (LP) gas is more dense or heavier than air and will more readily collect or pool in enclosed areas if adequate ventilation is not provided. It is not recommended to install LP gas heaters in enclosed areas such as pits. Locate heaters a safe distance from LP gas cylinders and filling equipment. Consult the National Fuel Gas Code (NFPA® 54/ANSI® Z223.1, latest edition), the Liquefied Petroleum Gas Code (NFPA 58, latest edition), the Natural Gas and Propane Installation Code in Canada (CAN/CSA B149.1, latest edition), and any other local codes and fire protection authorities about specific installation restrictions in your area.

IMPORTANT

For ALL installations the combustion air openings requirements and NFPA® 54 / ANSI® Z223.1 MUST be followed for safe and proper operation.

Section 5. Water Connections

Install pool system components with connections as illustrated in Figure 9. Any configuration other than as illustrated in Figure 9 can affect the operation of the water pressure switch. Locating the heater above or below the pool water surface can also affect operation of the water pressure switch.

NOTE: When pool equipment is located below the pool surface, Zodiac Pool System LLC is not responsible for any large scale water loss, flooding or damage caused by a leak.

⚠ CAUTION

The pool equipment must be protected from back-siphoning of water. If there is any chance of back-siphoning, provide a check valve between the pool and the filter pump inlet. See Section 5.5, *Check Valve Installation* for check valve guidelines.

5.1 Pump Sizing

For ASME compliant heater models JXIQ400NC, JXIQ400PC, JXIQ260NC and JXIQ260PC please see Section 14, *Appendix A. ASME® Compliant Header*.

All JXIQ heaters utilize an internal bypass mechanism and thermal regulator valve (TRV) to accommodate flow rates delivered to the heater from a minimum of 30 gallons per minute (gpm) to a maximum flow of 100 gpm.

⚠ CAUTION

The system water pump must be capable of providing no less than 30 gpm of flow through the heater. Flow rates at less than 30 gpm may cause nuisance operation causing damage to the heater or causing the heater to turn off.

MODEL	MIN GPM (LPM)	MAX GPM (LPM)
JXIQ 200	30 (114)	100 (379)
JXIQ 260	30 (114)	100 (379)
JXIQ 400	30 (114)	100 (379)

If pool is located in area with hard water, the minimum flow rate should be increased to 40 gpm or more to help prevent scaling.

Table 4. Recommended Flow Rate Adjustment




Figure 9. Typical Water Piping Configuration




Figure 10. Head Loss Chart

For ASME compliant heater models JXIQ400NC, JXIQ400PC, JXIQ260NC and JXIQ260PC please see *Section 14, Appendix A. ASME® Compliant Header*.

5.1.1 Manual Bypass Valve

A manual bypass valve is to be installed in any system in which the pump flow exceeds 100 gpm to the heater.

- Connect a valve between the water inlet and outlet. See inset "a" in Figure 9.
- Adjust the valve to bring the flow rate within the acceptable range. See Table 4.
- Remove the valve handle to avoid tampering.

5.1.2 Pump Sizing for New Pool Construction

When sizing a pump for the system, the head loss for all system components must be added together when determining the design flow rate. Component "Head Loss at Flow" curves are available from equipment manufacturers.

NOTE: In order to properly establish head loss at flow for a filter, remember that a "dirty" filter can typically add 10 psi of additional head loss (23 extra feet of head). This must be considered when sizing a pump for a new pool system.

5.1.3 Pump Sizing for Replacement in an Existing Pool

If the JXIQ heater replaces a different model of heater, determine if the existing pump is capable of providing the minimum flow of 30 gpm. JXIQ heaters are high efficiency heaters. Heaters typical of this construction may have higher head loss characteristics than the one being replaced.

5.2 Plumbing Connections

The heater has a standard 2 inch water manifold and coupling design. With this feature, only nominal two inch PVC or CPVC may be connected to the heater. However, by installing appropriate pipe adapters and two-inch pipe (supplied by the installer), any size existing pipe may be fitted to the heater.

5.2.1 Reversing Plumbing Connections

The JXIQ heater is shipped with the manifold on the right side by default. If necessary the water connections can be orientated to the left side by rotating the top panel of the appliance.

NOTE: The electrical raceway, transformer, PIB, ignition control and voltage selector board are all accessed through the default front panel. Special considerations should be made for service clearance, see Figure 2, before the final location and orientation of the appliance is determined.

1. Turn off all power to the heater at the breaker.
2. Ensure that the pump is off and will remain off for the duration of the procedure.
3. Remove the four black screws securing the heater top panel to the heater body.
4. Lift the heater top panel. Be careful not to damage or apply undue stress to the user interface wiring.
5. Rotate the heater top panel 180°.
 - Place the heater top panel on the heater body.
 - Secure with the four screws removed in step 3.
 - Restore power to the heater.
 - Return the heater to normal operation.

⚠ CAUTION

Heater failure due to insufficient water flow is not covered under warranty. See measurements in Figure 10.



NOTE: Maintain 12" US/24" CAN service clearance at "rear" of Heater when reversed.

5.2.2 Water Inlet Piping

For ASME compliant heater models JXIQ400NC, JXIQ400PC, JXIQ260NC and JXIQ260PC please see **Section 14, Appendix A. ASME® Compliant Header.**

There are two options for water inlet connections on the JXIQ. Both configurations use the same water outlet to return heated water to the pool. Be sure to check flow rates as outlined in **Section 5.1, Pump Sizing** and if necessary make provisions for and ensure sufficient space for the installation of a manual bypass valve as outlined in **Section 5.1.1, Manual Bypass Valve.**

The top inlet is intended for use with the Jandy Versa Plumb® sweep elbow. Plumbing in this configuration can increase hydraulic efficiency particularly when used in a system with other Versa Plumb compatible, Jandy Equipment. See **Figure 11.**




Figure 11. Versa Plumb Heater Inlet

The sweep elbow also provides the advantage of its exclusive interface with the Jandy AquaLink® RS temperature sensor.

The side inlet is positioned at a 10 1/8 in (255.7 cm) center height providing an ideal height for replacement unit or new construction plumbing.

1. Turn off all power to the heater at the breaker.
2. Turn off main gas supply to heater.
3. Ensure that the pump is off and will remain off for the duration of the procedure.
4. Do a dry fit test of cut pipe lengths in order to ensure proper seating of the union tailpiece and o-ring. Make adjustments to pipe length or positioning as needed.
5. Clean all adhesion surfaces with an appropriate NSF® approved all purpose cleaner/primer.

6. Slide the union nut onto the cut pipe length or sweep elbow. Ensure proper nut orientation with threads directed towards the heater manifold. See **Section 5.2.2, Water Inlet Piping.**
7. Use approved NSF adhesive to glue the tailpiece onto the cut pipe, or sweep elbow.

NOTE: Zodiac Pool Systems LLC recommends Weld-On® 724™ PVC to CPVC Cement to glue Schedule 40 PVC.

8. Align tailpiece and manifold orifice.
9. Secure to manifold with union nut hand tight only. Do not over tighten. **Do not** use pipe joint or thread tape.
10. If using the sweep elbow. Use approved NSF adhesive to glue the sweep elbow onto the cut pipe.

11. Repeat the above steps for the manifold outlet. Again paying special care to ensure proper seating of the union tailpiece o-ring.
12. Install the union nut and drain cap with o-ring at the unused inlet on the heater manifold. Be sure that the o-ring is properly seated. Secure hand tight only. Do not over tighten. **Do not** use pipe joint or thread tape.
13. Relocate the Sacrificial Anode to the horizontal inlet port. Refer to *Section 5.3, Sacrificial Anode Replacement*.
14. Return all valves to their operating positions.
15. Restore power to the heater at the breaker.
16. Turn on pump and inspect carefully for leaks.
17. Restore main gas supply.
18. Start the system and check for proper flow.
19. Return heater to normal operation.




Figure 12. Inlet Piping

⚠ WARNING



Never approach, inspect or attempt to troubleshoot any leaking valves or plumbing without turning off all electrical power to the system. Failure to turn off all electrical power can result in electrical shock, serious injury or death. Ensure that all electrical power to the system is turned off before approaching, inspecting or troubleshooting any leaking valves or plumbing that may have caused other electrical devices in the surrounding area to get wet.

⚠ WARNING



Follow all filter manufacturer's instructions. Never attempt to assemble, disassemble or adjust the filter when there is pressurized air in the system. Starting the pump while there is any pressurized air in the system can cause the filter lid to be blown off, which can cause death, serious personal injury or property damage.

5.3 Sacrificial Anode Replacement

The sacrificial anode is installed from the factory on the upper inlet of polymer headers only.

1. Disconnect power to the pump and heater at the breaker.
2. Turn off the main gas supply to the heater at the meter or the manual gas valve outside the heater.
3. Remove the existing Sacrificial Anode assembly from the header.

NOTE: Location of the alternate inlet cap depends on the plumbing.

4. Remove all the screws from the right panel and the two center screws from the left panel to access the header studs.
5. Remove the nut that secures the wire to the header, remove the wire.
6. Install the anode assembly, and hand-tighten the union nut until secured on the header.




Figure 13. Removal Panel / Install Anode

7. Guide the anode wire through the grommet.
8. Attach the anode bonding wire ring terminal to the header stud with the provided flange nut. Do not overtighten.

NOTE: It may be necessary to remove security check paint from the stud.




Figure 14. Secure Bonding Wire

9. Secure the header panel back onto the heater using the screws.
10. Restore power to the heater and to the pump.
11. Verify there are no leaks or bubbling around the inlet.

NOTE: Periodically check the anode cylinder for deterioration. Deterioration rates vary by pool/spa water conditions.

5.4 Water Pressure Switch Adjustment

The water pressure switch is inside the heater jacket on the water connection side. See *Section 1.7, Heater Components*.

The switch is preset at the factory. The pressure switch setting must be adjusted if the heater is installed:

- Below the surface level of the pool
- More than two feet above the pool level
- Where the pressure is measured at 1 psi or greater with the filter pump off

Location of the heater above or below the pool water surface can also affect the operation of the switch. The factory installed switch can accommodate elevations of 6 feet above the pool water surface or 11 feet below the pool water surface. If the heater water connections are outside this range Consult your local Zodiac® representative for recommendations.

1. Set the heater control to "OFF".
2. Remove seven screws securing the side panel to the heater body.
3. Remove the side panel to gain access to the water pressure switch. See *Figure 15*.
4. Turn the filter pump on and confirm that the pressure switch closes with a voltmeter.
5. If the switch does not close, check that all valves are open to the heater and that there are no restrictions in the line. You may also need to confirm flow rate from your pump as outlined in *Section 5.1, Pump Sizing*.




Figure 15. Water Pressure Switch Adjustment

⚠ CAUTION

The water pressure switch should be adjusted to turn the heater off when the pump is off. Setting the switch to close at too low flow can damage the appliance. Adjust the switch to turn the heater off, not on.

NOTE: It is recommended that a Pressure Release Valve (PRV) be installed prior to taking any of the steps below. Please see Section 5.6, *Pressure Relief Valve Installation* for details.

- Once an operational and correctly sized pressure switch has been confirmed, set the heater control to either POOL or SPA. Heater should start.
- With your fingers, turn the adjustment sprocket very slowly clockwise until the heater goes off.
- Slowly turn the pressure switch adjustment sprocket counterclockwise one-quarter turn. The heater should come back on. See Figure 15.
- Check the adjustment by turning the filter pump OFF. The burner should shut off immediately. If it does not, restart the filter pump and repeat the preceding step. Check the adjustment again. If you are still unable to successfully set your water pressure switch please contact your local Jandy distributor or call technical support at 1.800.822.7933. Additional information can be found at www.jandy.com.
- Return the temperature control to the desired temperature.

5.5 Check Valve Installation

When any equipment is located below the surface of the pool or spa, back-siphoning can occur, which can draw water backwards through the circulation system. This can be particularly concerning if chemically treated water is allowed to flow back into equipment such as heaters, filters and pumps. Make sure any chemical feeder or chlorination system outlet lines are downstream of the heater and a positive seal noncorrosive check valve is installed between the sanitation equipment and the heater. Always install a check valve if there is sanitation equipment installed in the system. **Do not** install any shutoff valve in the piping between the heater outlet and the pool.

⚠ WARNING

A check valve can interfere with the proper operation of certain Suction Vacuum Release System (SVRS) products. To avoid possible entrapment hazard, serious injury, or death, make sure to review the operation/owners manual of your particular SVRS product before installing the check valve.

5.6 Pressure Relief Valve Installation

A pressure relief valve (PRV) is recommended in all installations, and is mandatory in any installation in which the water flow can be restricted between the heater outlet and the pool/spa. A pressure relief valve may also be required by local codes. Be sure to check any applicable installation codes in your area to determine whether a pressure relief valve is required.

A pressure relief valve is not supplied with the JXIQ heater. However, Jandy does offer a PRV Kit # R0336101. The following instructions are for use with this kit only. All other equipment installations need to be in accordance with the manufacturers instructions.

The maximum working pressure of this heater is 50 psi. Be sure to take into consideration the maximum allowable pressure of the other components in the system when installing a PRV. Any pressure relief valve installed must comply with provisions of the standard described in ANSI® Z21.22 for the United States or CSA 4.4 in Canada.

5.6.1 Install Pressure Relief Valve Kit #R0336101

For ASME compliant heater models JXIQ400NC, JXIQ400PC, JXIQ260NC and JXIQ260PC please see Section 14, *Appendix A. ASME® Compliant Header*.



Item	Description	Header Type	
		A	B
1	Pressure Relief Valve 3/4 in X 3/4 in 50 PSI	X	X
2	Brass Nipple 3/8 in	X	
3	Reducer Bushing 3/8 in M to 3/4 in F NPT	X	
4	Brass Nipple 3/8 in		X
5	Elbow 90° 3/4 in NPT Brass	X	X
6	PTFE (Teflon™) Tape	X	X

Table 5. Pressure Relief Valve Kit Components/Usage




Figure 16. Header

- Turn off the electrical power to the heater.
- Turn off the main gas supply to the heater.
- If the heater has been operating, ensure you allow enough time for remaining water in the heat exchanger to cool down before beginning. It is recommended that protective gloves be worn during the entire procedure.
- Make sure the filter pump is off and will remain off for the duration of the installation procedure.
- If the heater is below the surface level of the water in the pool or spa, close all shut-off valves between the heater and the pool.

CAUTION

Use PTFE (Teflon™) tape only on the threads of the pipe nipple attachment to the plastic header. **Do not use pipe compound or pipe dope** on threads or any part that comes into contact with the plastic header. These compounds may damage the header over a period of time.

- Remove drain plug/outlet temperature sensor from header and allow all water to drain from heat exchanger, see Figure 17.




Figure 17. Remove Drain Plug/Temp Sensor

- Locate the threaded boss on the outlet port of the header, and find the dimple at the center.
 - Use the dimple to center the drill bit. Drill a 3/8 in (9.5 mm) diameter hole through the boss. **Take care not to damage the plastic threads.**
- TIP:** Drilling a 1/8 in (3 mm) diameter hole first will help prevent thread damage.
- Each male connection should be first wrapped in 5-8 turns of PTFE (Teflon™) tape.
 - Assemble the 3/4 in threaded nipple, elbow and pressure relief valve. Make sure to get a snug fit. Do not over tighten.
 - Install the pressure relief valve assembly at the heater header. Make sure to get a snug fit. Do not over tighten.




Figure 18. Install Pressure Relief Valve

- The final orientation of the pressure relief valve should be vertically aligned with the discharge opening facing away from the heater header.
- Install a discharge pipe from the pressure relief valve discharge opening to a safe area. This is a precaution to prevent the possibility of personal injury or property damage in the event scalding water is discharged from the pressure relief valve.
- Install the discharge pipe so that there is no trapped or standing water in the piping. Discharge piping must be facing down, terminating with a threadless nipple, no more than 6 in (152 mm) and no less than twice the diameter of the discharge pipe from the floor or drain/receptor.




Figure 19. Install Discharge Pipe

- Discharge piping must be open with no reducers or shut-off valves or other restrictions.
- Discharge piping must be positioned so that any discharged water will have an appropriate drain or run-off path away from the heater and other pool equipment.
- To ensure the continued proper operation of the pressure relief valve, the valve should be tested once a year. To test, lift the lever with the circulation system running to ensure that water will pass through. When the lever is down, there should be no leaks from the outlet.
- All sanitation equipment, including chemical feeders and ozone generators, will need to be installed as the last piece of equipment in the pool circulation system.
- A chemically resistant check valve will also need to be installed between the sanitation equipment and the heater to prevent back-flow of high concentration of sanitizer from entering the heater.
- Wire any electrical sanitation equipment so that it cannot operate unless the filter pump is running.
- Always follow pool chemical manufacturer's instructions when adding chemicals to pool.

5.7 Auxiliary Components, Chlorinators, Ozone Generators and Sanitizing Chemicals

The JXIQ heater is manufactured with materials that are not compatible with high concentrations of ozone, chlorine, bromine, or other sanitizing chemicals. Heater damage caused by improper water chemistry or plumbing configurations are not covered by the Zodiac Pool Systems LLC warranty. All questions should be directed to technical support at 1.800.822.7933. Additional information can be found at www.jandy.com. Be sure to adhere to the following:

Section 6. Electrical Connections

The heater is equipped with dual voltage auto sensing for both 115/230 VAC 60Hz. For wiring instructions see **Section 6.2, Main Wiring Connections**.

Wiring connections must be made exactly as shown in the wiring diagram found on the inside of the heater door. The NEC and CEC also require that the equipment and/or appliances associated with the pool water circulating system, including, but not limited to, pump motors and heaters, be bonded together as part of the equipotential bonding grid. Zodiac Pool

Systems LLC provides a special labeled bonding lug on the manifold side of the heater to accommodate this requirement.

All electrical connections and wiring must be done by a certified electrician only. Electrical wiring must also be in accordance with the latest edition of the National Electrical Code® (NEC®), ANSI®/National Fire Protection Association® (NFPA®) 70, or in Canada, the Canadian Electrical Code (CSA® C22.1) unless local code requirements indicate otherwise.

⚠ WARNING

ELECTRICAL SHOCK HAZARD. This heater contains wiring that carries high voltage. Contact with these wires may result in severe injury or death.

⚠ CAUTION


Label all wires prior to disconnection when servicing controls. Wiring errors can cause improper and dangerous operation.

Verify proper operation after servicing.

6.1 Service Access

Remove the four screws holding the front heater panel in place to expose the raceway.

- Locate the raceway lock release on the interior of the heater raceway.
- Using a screwdriver or comparable tool; press into the raceway release orifice until the raceway latch releases, and the raceway swings free.
- Secure the raceway in place by lifting until the locking latch engages.
- Push the tab on the locking latch to the left to release.



- Press raceway down and back until an audible click indicates that it is latched in position.
- Replace heater front panel.

TIP: For greater access remove the top panel by removing the 4 black screws on the outside of the heater.


NOTE: Before the raceway can be rotated for the first time a shipping zip tie must be cut. This zip tie is threaded at the raceway release point see item (a). While cutting this zip tie be sure not to damage or abrade any of the wires.

6.2 Main Wiring Connections

The JXIQ smart heater is equipped with dual voltage auto sensing input. When either 115 or 230 VAC are connected, the heater will sense the input power and configure itself automatically, no manual action required.

The main wiring connections should be available externally to the heater at the time it is unpacked. Use flexible conduit to run the main power lines from the power source to the heater connections. No external junction box is required.

- Ensure that all electrical power is shut off to the heater at the breaker.
- Ensure that the filter pump is off and will stay off for the remainder of the procedure.
- Follow applicable service access instructions from Section 6.1, *Service Access*.
 - Run conduit and power lines from main power source to the heater side panel.
 - Use wire nuts to connect L/L1 to Black, N/L2 to Red, and Gnd to Green.
 - Push wire connections through the knockout into the heater body. Be careful not to damage or abrade any wiring during this procedure.
 - Secure the conduit to the heater body panel at the knockout using a suitable conduit connector or elbow.



IMPORTANT

Maintenance Disconnect Means - The National Electrical Code® (NEC®) requires one or more means to simultaneously disconnect all ungrounded conductors to be provided for all utilization equipment other than lighting. Each means shall be readily accessible and within sight from its equipment and shall be located at least 1.5 m (5 ft) horizontally from the inside walls of a pool or spa unless separated from the open water by a permanently installed barrier that provides a 1.5 m (5 ft) reach path or greater.

GFCI Protection - Circuits serving gas-fired swimming pool and spa water heaters operating at voltages above the low-voltage contact limit per NEC® shall be provided with GFCI protection.

Canadian Electrical Code requires GFCI protection for all equipment located within 3 m of the inside walls of a pool or spa, unless separated from the pool or spa area by a fence, wall, or other permanent barrier.




Figure 20. Auto Voltage Sensing Diagram




Figure 21. Wiring Diagram for 230/115 VAC Installations

6.3 Bonding

In the United States the National Electrical Code® (NEC®) and in Canada the Canadian Electrical Code (CEC), require that all metallic components of a pool structure, including reinforcing steel, metal fittings and above ground components be bonded together (forming an equipotential bonding grid) with a solid copper conductor not smaller than an 8 AWG (6 AWG in Canada).

Additionally, Zodiac Pool Systems LLC, requires that the appliance be connected to a bonding loop that includes all electrical equipment in the system and on the equipment pad. Bonding lugs must be connected with a solid copper wire at least 8 AWG (6 AWG in Canada) or larger. Failure to do so may void the Zodiac Pool Systems LLC warranty.

⚠ CAUTION

To prevent premature failure of the appliance resulting from stray voltages and voltage differentials, the heater must be bonded to other equipment which is part of the pool plumbing system with a solid copper wire not smaller in diameter than 8 AWG (6 AWG) in Canada.

National Electrical Code® (NEC®) requires bonding of the Pool Water. Where none of the bonded pool equipment, structures, or parts are in direct connection with the pool water; the pool water shall be in direct contact with an approved corrosion-resistant conductive surface that exposes not less than 5800 mm² (9 in²) of the surface area to the pool water at all times. The conductive surface shall be located where it is not exposed to physical damage or dislodgement during usual pool activities, and it shall be bonded in accordance with the bonding requirements of NEC Article 680. Refer to locally enforced codes for any additional bonding requirements.

Section 7. Optional Remote Controls

The JXIQ heater controls can be wired for remote operation. All Jandy AquaLink® Control Systems will permit the heater to be operated by remote control. The instructions in the following sections should be used as a general guideline only. Please follow the instructions that accompany your selected control system thoroughly.

If you are setting up a new pool or spa system, or if you have any questions about your heater control system, please call Jandy technical support at 1.800.822.7933.

Electrical wiring must be in accordance with the latest edition of the National Electrical Code (NEC), ANSI®/National Fire Protection Association® (NFPA70®), unless local code requirements indicate otherwise.

Refer to Figure 21 for a complete diagram of wiring connections and terminals.

Consult with Jandy Technical Support, 1.800.822.7933 for questions about installing non-Zodiac remote controls.

7.1 Connecting to a Remote Pool-Off-Spa Selector (3-Wire Connection)

- Turn off the power to both the pool/spa control system and the heater unit.
- Follow service access instructions from Section 6.1, Service Access.
- Run the wires from the pool/spa control system through the low voltage knockout on the right or left hand side of the heater.
- Connect the wiring from the pool/spa control system to the heater remote control terminal. See Figure 21.
- Connect the three wires to the Spa, Pool & Common terminals of the P10 terminal bar.
- Reinstall front panel.
- Restore power to the heater and the pool/spa control system.

7.1.1 Configure the Control Panel

- Make sure the pool heater is OFF.
- Press and hold MENU, then the POOL and SPA buttons for 5 seconds to access Service Setup mode.

NOTE: The display will revert back to OFF 2 minutes after the last key press.

- Press Up or Down to display REMOTE.
- Press ENTER, STANDALONE (default) is displayed.
- Use Up or Down to scroll through the Remote options until HI-LO-COM is displayed, then press ENTER to select.
- Press MENU to exit Service Setup mode.

7.2 Connecting to an AquaLink® Control System or Remote TSTAT (2-Wire Connection)

An interrupt (on/off-type) remote can be connected as a Remote TSTAT to turn the heater on or off but not perform any other function. When using this type of connection, remember to set the heater control to "pool" or "SPA" and set the thermostat control to maximum.

7.2.1 Install the Remote TSTAT

- Turn off the power to both the pool/spa control system and the heater unit.
- Follow service access instructions from Section 6.1, Service Access.
- Run the wires from the pool/spa control system through the low voltage knockout on the right or left hand side of the heater.
- Connect the wiring from the pool/spa control system to the heater remote control terminal.
- If you want the Pool button on the heater user interface to be active in this mode, connect the two wires to Pool and Common on the control board (P10 terminal bar on the board).
- If you want the SPA button on the heater user interface to be active in this mode, connect the two wires to Spa and Common on the control board (P10 terminal bar on the board).
- Reinstall panel.
- Restore power to the heater and the pool/spa control system.

NOTE: If you install a time clock to control the filter pump operation, it is recommended that the time clock have its own low voltage (Fireman's) switch to turn off the heater before turning off the pump. The switch should shut off the heater about 15 minutes before the filter pump shuts off. This will allow for a more efficient operation by removing any residual heat contained in the heat exchanger back to the pool.

CAUTION

To avoid damage to the heater, **do not connect the power supply of the heater to the output side of the clock** if your time clock simply interrupts the high voltage power supply or has a high voltage output. Doing so will prevent the blower from purging the residual heat from the heater when the heater turns off. The blower must be allowed to run for 45 seconds after the heater shuts off.

7.2.2 Configure the Control Panel

- Make sure the pool heater is OFF.
- Press and hold MENU, then the POOL and SPA buttons for 5 seconds to access Service Setup mode.

NOTE: The display will revert back to OFF 2 minutes after the last key press.

- Press ENTER, STANDALONE (default) is displayed.
- Use Up or Down to scroll through the Remote options until REMOTE TSTAT is displayed, then press ENTER to select.

- Press MENU to exit Service Setup mode.
- Press POOL or SPA to adjust the set point to the maximum 104°F (40°C).

7.3 "Smart" Communication via RS-485

To provide "smart" communication between the JXIQ and a power center board (PCB) (AquaLink RS, AquaLink PDA, and AquaLink Z4) through a red four-pin RS485 connector, your PCB must have the appropriate firmware. To determine the REV of the AquaLink RS PCB firmware in your system, refer to Table 6.

7.3.1 PCB and Firmware Identification for AquaLink RS and AquaLink PDA Connections

COMPONENTS	REV MMM OR EARLIER	REV N OR LATER
RS485 Connectors	One set of four	Two sets of four
JWA Sockets 24 VAC	Located on top of board	Located on bottom of board
Relay Sockets 24 VDC	10 total sockets. Eight located on bottom, two on top of board.	11 total sockets. All located on bottom of board.

Table 6. AquaLink RS Power Center Board Identifying Features




Figure 22. Wiring the JXIQ to a Jandy Remote

If your PCB firmware is REV MMM or earlier:

Connect via a 2-wire connection. See *Section 7.2, Connecting to an AquaLink® Control System or Remote TSTAT (2-Wire Connection)* for details.




Figure 23. AquaLink RS PCB with Firmware REV MMM or Lower

If your PCB firmware is REV N or higher:

Connect via RS485 connection. See *Section 7.3.2, RS485 Connection Procedure* for details.




Figure 24. AquaLink RS PCB with Firmware REV N or Higher

NOTE: Only an AquaLink® RS System with firmware revision "N", or higher, will support the heater interface. Refer to Table 6 along with Figure 23 and Figure 24 to determine the REV of your system's firmware. If it is "N" or higher, continue with these procedures. If it is MMM or lower, follow the procedures in Section 7.2, *Connecting to an AquaLink® Control System or Remote TSTAT (2-Wire Connection)* for connecting to a remote TSTAT.

NOTE: Only a PDA System with firmware revision 4.1, or higher, will support the heater interface.

7.3.2 RS485 Connection Procedure

- Turn off the power to both the heater and the controller.
- Open the power center enclosure and remove the low voltage dead front.
- Use 22 gauge 4-conductor wire to run between the heater and the control system and match the wire color order. See Figure 22.
- The wires coming from the heater can be "doubled up" on the red RS485 terminal bar with the four wires from the indoor controller.
- Check all wiring, then apply power to both the heater and the control system. Verify operation in either Service or Auto mode. Refer to your Control System manual for operating instructions.

When the heater is connected to an external controller, all functionality of the heater control panel is disabled, therefore heater functions can be controlled only from the controller. Control can be restored to the local heater control panel by either disconnecting the red RS485 terminal or by entering the service setup mode selecting REMOTE then STANDALONE. Control can be sent back to the external controller by re-entering the service setup mode and selecting REMOTE RS-485, unplugging and replugging the RS485, or by cycling power to the heater with the RS485 connected.

Do not connect more than two (2) wires to any of the terminals in the Control System when connecting peripheral devices. If connecting the heater to the control system creates this situation, then a Multiplex PCB Kit, which includes the Multiplex Board (part # 6584) must be used. Call Jandy Technical Support at 1.800.822.7933 with any questions.

- To reduce electromagnetic noise, near the RS-485 connector install a snap on ferrite to the RS-485 cable, see Figure 25.

NOTE: When the heater is powered by 120 VAC, to reduce electromagnetic noise, run the RS-485 cable through a snap-on ferrite close to the RS485 connector, as shown in Figure 25. Contact Fluidra customer service for a ferrite kit (PN# R1029700), provided free of charge. (Ferrite specs: Fair-Rite PN# 0431164281).




Figure 25. Install Ferrite

7.3.3 To Stop the Heater and Prevent Firing After Connecting to an External Controller

- Turn power to the heater ON. The heater display shows: **JANDY REMOTE ONLINE PUSH MENU TO DISABLE.**
- After pressing menu, the display will show **JANDY REMOTE OFFLINE PUSH MENU TO ENABLE.**

7.3.4 To Revert Heater Control Back to Local Heater User Interface

To revert the heater back to Standalone without disconnecting the RS-485:

- Make sure the pool heater is OFF.
- Press and hold MENU, then the POOL and SPA buttons for 5 seconds to access Service Setup mode.

NOTE: The display will revert back to OFF 2 minutes after the last key press.

- Press Up or Down to display REMOTE.
- Press MENU, REMOTE RS-485 is displayed.
- Use Up or Down to scroll through the Remote options until STANDALONE is displayed, then press MENU to select.
- Press MENU to exit Service Setup mode.

7.3.5 Calibrate Water Sensors

You can calibrate the sensor reading on both the heater and the RS connected device.

To calibrate from the heater go to the user interface on the heater when the heater is in OFF mode.

- Press the POOL, SPA, and MENU buttons simultaneously for 5 seconds.
- From the Service Menu, scroll down to the WATER TEMP CAL menu option with the arrow buttons and then press ENTER. The following screen will appear:

SELECT H2O TEMP CAL
+0° F

- Adjust the heater sensor reading in 1F increments up to +2F and down to -2F.
- Press ENTER when you reached desired calibration adjustment. This will take you back to the Service Menu listings.
- Press MENU to exit the Service Menu.

NOTE: The thermostatic control will register off of the inlet water sensor that is in the heater on a device connected via RS-485 communication. It is possible for the water sensor that is connected directly to the remote power center device to read slightly different temperature than the heater sensor.

To calibrate from an RS connected device go to your device when the heater is in OFF mode.

- From the HOME screen, press WEB.
- From the SYSTEM SETUP, press the right arrow.
- On the next screen, press the MENU icon.
- From the MENU screen, press SYSTEM SETUP.
- From the SYSTEM SETUP screen, select TEMP CALIBRATE to calibrate the temperature.



Section 8. Bluetooth® Pairing

Follow the instructions below to pair your WiFi and Bluetooth enabled device (phone or tablet) to your smart heater.

NOTE These steps will work for both Android and iOS devices.

1. Open the JXIQ smart heater UI cover and open the Fluidra Pro app on your device.




Figure 26. Open Fluidra Pro

2. Log into Fluidra Pro app using your User ID and password.
3. Press menu on the lower right hand corner.




Figure 27. Fluidra Pro Menu

4. Press resource center.



Figure 28. Fluidra Pro Resource Center

5. Press connect to JXIQ heater.




Figure 29. Fluidra Pro Connect to JXIQ Heater

6. Hold down the menu button on the heater display for 5 seconds, the heater ID will be displayed at the top right of the screen.



Figure 30. Heater ID on User Display

7. Confirm the JXIQ heater ID for the device and select it in the app to begin pairing.
8. Enter the 6 digit PIN number that appears on the UI, and press pair.
9. Once device has paired the JXIQ diagnostics screen will appear.




Figure 31. Fluidra Pro JXIQ Diagnostics

Section 9. Operating Instructions

Follow the instructions outlined below to start the heater. Refer to the Lighting and Shutdown Instructions label on the inside lid panel of the heater. All questions should be directed to technical support at 1.800.822.7933. Additional information can be found at www.jandy.com.

⚠ WARNING

If you do not follow the instructions below exactly, a fire or explosion may result, causing property damage, personal injury or death.

9.1 Important Safety Information

Read Before You Start

This appliance does not have a pilot light. It is equipped with an ignition device, which automatically lights the heater. Do NOT try to light the burners by hand.

BEFORE OPERATING, smell all around the appliance for gas. Be sure to smell next to the floor because some gas is heavier than air and will settle on the floor.

9.1.1 What To Do If You Smell Gas

- Do not try to light any appliance.
- Do not touch any electric switch; do not use any phone in your building.
- Immediately call your gas supplier from a neighbor's phone. Follow the gas supplier's instructions.
- If you cannot reach your gas supplier, call the fire department.
- Use only your hand to switch on or off the gas control switch. Never use tools.
- If the gas control switch appears broken or will not move, don't try to repair it, call a qualified service technician. Force or attempted repair may result in fire or explosion.
- Do not use this appliance if any part has been under water. Immediately call a qualified service technician to inspect the appliance and to replace any part of the control system which has been under water.

9.2 First-Time Start-Up Procedure

⚠ WARNING

Vent pipes and heater tops get hot! These surfaces can cause serious burns. Do not touch these surfaces while the heater is in operation.

Do not use this heater if any part has been under water. Immediately call a qualified service technician to inspect the heater and replace any part of the control system and any gas control which has been under water.

Should overheating occur or the gas supply fail to shut off, turn off the manual gas control valve to the heater. Do not attempt repairs on the gas controls or appliance. Tampering is dangerous and voids all warranties.

- Confirm that pool water is flowing normally through the pool system and equipment.
- If it is a new pool or spa installation, operate the filter pump with the heater off long enough to completely clean the water. This will remove any installation residue from the water.
- Clean the filter before starting the heater.
- Start the heater in either Pool or Spa mode. See Lighting and Shutdown Instructions label on top panel.
- Start the heater. See Lighting and Shutdown Instructions label on top panel.
- When the heater starts, confirm there is adequate water flow. See Section 5, Water Connections for details.

9.2.1 Operating Instructions

Refer to the Lighting and Shutdown Instructions. See Lighting and Shutdown Instructions label on top panel.

- **STOP! Read IMPORTANT SAFETY INFORMATION in previous section.**

- This appliance is equipped with an ignition device which automatically lights the heater. **DO NOT** try to light the burner by hand.
- Set temperature thermostat controls to their lowest setting and turn off the controller. Make sure the display shows GAS HEATER IS OFF.
- Turn off all electrical power to the heater at the junction box.
- Remove the heater rear or top panel.
- Toggle gas control switch to OFF position. See Figure 32.
- Wait five (5) minutes to clear out any gas, then smell for gas, including near the floor. IF YOU SMELL GAS, STOP! Follow instructions in **What To Do If You Smell Gas** (see Section 1.1, Safety Instructions).
- If no gas is detected, toggle gas control switch to the ON position.
- Replace the rear panel or top.
- Turn on electrical power to the heater.
- Turn the controller ON by pressing POOL or SPA and set the temperatures as necessary.




Figure 32. Gas Valve

NOTE: If the heater does not start, check that the filter pump is ON, the filter is clean and that water is flowing to the pool. If the heater still does not operate, follow the procedure in Section 9.3, To Turn Off Gas to the Heater.

⚠ WARNING

When the heater is fired for the first time, the combustion chamber refractory binder material is driven out by the heat of the flame. White smoke and/or sharp odors may be emitted from the vent during this period. Do not inhale combustion product fumes at any time, and especially when these fumes are being emitted. This "burn-in" period will last only a few minutes.

9.2.2 If Ignition Is Unsuccessful

If ignition is unsuccessful, or the flame fails during normal operation, the ignition control shuts off the gas valve. The heater will then go through a post purge process and attempt to establish stable combustion two additional times. If ignition is unsuccessful after three attempts, the system will lock out.

- To reset the heater to provide three (3) attempts to start:
- Turn OFF power at the breaker for power cycle, then turn it back ON.
- Access either the Pool or Spa mode.

9.3 To Turn Off Gas to the Heater

- Set temperature thermostat controls to their lowest setting and turn off the controller. Make sure the display shows GAS HEATER IS OFF.
- Turn off all electrical power to the heater at the junction box.
- Remove the rear panel or top.
- Toggle gas control switch to OFF.
- Shut off the external gas supply valve to the heater.
- Replace the rear panel or top.

9.4 Normal Operation

During normal operation, the control system measures the temperature of the water flowing through the heater and will begin the start-up process if the temperature is below the set point. If the blower pressure switch senses adequate airflow when the blower starts, the ignition sequence begins. Following a pre-purge, the igniter is energized, then the gas valve opens. As long as a flame is sensed at the burner, operation continues until the temperature of the water entering the heater reaches the temperature control setting.

⚠ WARNING

Never bypass, disconnect, or render inoperable the flue temperature sensor, high limit switches, water temperature sensors, water pressure switch, gas pressure switch and air pressure switches. Doing so may result in property damage, serious injury or even death, including but not limited to from carbon monoxide poisoning.

9.5 Operating the Controller

Unless the heater is connected to a remote controller, all operations are set up and programmed through the control panel on the top of the heater. See Figure 33.

NOTE: The display light reverts to OFF after two minutes of inactivity since the last key was pressed.



Figure 33. Main Control Panel

9.5.1 Setting up Heater Options

Before using the heater for the first time, set up the following options:

- **Languages:** Set a display language
- **Temperature Scale:** Set temperatures to be displayed in either Celsius or Fahrenheit scale
- **Display Light Timeout:** Set the display light to turn off after a specific interval of inactivity

To Program the Display Language

Heater must be in OFF mode to begin



Hold for 5 Seconds



or

SELECT USER
SETUP LANGUAGE



SELECT LANGUAGE
ENGLISH



or

To Change Language



To Save



To Exit

To Program the Temperature Scale (F or C)

Heater must be in OFF mode to begin.



Hold for 5 Seconds



or

SELECT USER
SETUP
TEMPERATURE SCALE



SELECT TEMP SCALE
°F



or

to Toggle °F and °C



To Save



To Exit

To Program Display Light to Turn Off Automatically

Heater must be in OFF mode to begin



Hold for 5 Seconds.



or

SELECT USER
SETUP DISPLAY LIGHT



SELECT DISPLAY LIGHT
2 MIN TIMEOUT
LIGHT OFF
LIGHT ON



or

to Toggle:




To Save




To Exit

9.5.2 Operating the Heater

To Turn on Pool or Spa Heat



To Turn the Heater Off




When the control panel is OFF, the screen displays:


GAS HEATER IS OFF
PRESS POOL OR SPA

Temperature Set Point Lock

Once you have programmed pool temperature and spa temperature set points, you can lock them so that they may not be changed inadvertently.



Heat Up Time Estimate



A heat up time estimate is provided on the JXIQ's main display under "ESTIMATE". This provides the user with an estimate of how long it will take to reach the desired target temperature. The estimate will become more accurate after about 10 heating cycles as it is a dynamic learning algorithm. For example: If the JXIQ displays an estimate of 8 hours, that estimate is based on 8 hours of straight heating time. Heating the pool only during the filter cycle time will cause the pool to take longer to heat due to the over night loss of heat. Pool covers greatly reduce the heat up time and save on energy costs.

9.6 Performing Seasonal Shutdown

For complete shutdown instructions refer to the Lighting and Shutdown Instructions label on top panel. For winterization instructions see *Section 10.3, Winterizing*.

- Set temperature thermostat controls to their lowest setting and turn off the controller. Make sure the display shows OFF.
- Turn off all electrical power to the heater at the junction box.
- Remove the top panel of the heater.
- Turn the gas valve control switch to OFF.
- Shut off the external gas supply valve to the heater.
- Replace the top panel.

Section 10. Maintenance

If the heater is not going to be used for an extended period of time and in colder climates, follow seasonal shutdown instructions. See *Section 9.6, Performing Seasonal Shutdown*, and Lighting and Shutdown Instructions label on top panel.

IMPORTANT

MAINTENANCE NOTE

We recommend that before each pool season, the Thermal Regulator Valve (TRV) be inspected for proper operation and replaced if there are signs of scaling or corrosion.

Corrosion and scaling are the result of improperly balanced water. Please see *Section 10.1.1, Saturation Index* for complete details on managing your water chemistry.

The TRV ensures the heater operates at its optimal efficiency and if properly maintained will extend the life of the heater.

⚠ WARNING

Do not operate the heater if the water temperature is below 40°F (4°C).

- Short term operation of heater when ambient temps are below 40°F can continue but continuous flow must be maintained.
- Prolonged operation with water below 50°F can seriously damage the heater and is not covered by warranty.

10.1 Water Chemistry

Proper Water Balance is the key to the enjoyment of your pool or spa experience and to the long life of your heater.

The pH of your pool or spa's water is one of the factors that has the most impact on indicating how properly balanced the water is. The other factors are: temperature, total alkalinity, calcium hardness and total dissolved solids. Cold water is typically more acidic (corrosive), while hot water tends to lead to a scale forming (basic) condition. While the heater is in

operation, if the pH is allowed to rise above 7.8 and the calcium hardness and total alkalinity are not properly maintained, calcium in the water could lose solubility, coating the copper tubes inside the heat exchanger. This will restrict the flow of water resulting in reduced efficiency and possible damage to the heater.

If the pH is allowed to drop below 7.2, and the alkalinity is not properly maintained, the water will become more acidic. Acidic water has a tendency to dissolve metal components in the pool plumbing such as copper tubing in the heat exchanger.

Recommended Levels	Fiberglass Pools	Fiberglass Spas	Other Pool and Spa Types
Water Temperature	66-88°F (20-31°C)	89-104°F (31-40°C)	68-104°F (20-40°C)
pH	7.3 - 7.4	7.3 - 7.4	7.6 - 7.8
Total Alkalinity (ppm)	120 - 150	120 - 150	80 - 120
Calcium Hardness (ppm)	200 - 300	150 - 200	200 - 400
Salt (ppm)	4500 Maximum	4500 Maximum	4500 Maximum
Free Chlorine (ppm)*	2 - 3	2 - 3	2 - 3
Total Dissolved Solids (ppm)	3000 Maximum**	3000 Maximum**	3000 Maximum**

*Free Chlorine MUST NOT EXCEED 5 PPM!

**In saltwater chlorinated pools, the total TDS can be as high as 6000 ppm.

Table 7. Pool Water Chemistry

10.1.1 Saturation Index

pH, Total Alkalinity (TA), temperature, Calcium Hardness and Total Dissolved Solids (TDS) play a role in whether the water is either corrosive or scale forming. These factors are combined in the Langelier Saturation Index, which is a method for determining whether or not water is properly balanced. See Table 8.

Saturation Index = pH + AF + CF + TF - 12.1*					
A-Factor=(AF), C-Factor=(CF), T-Factor=(TF)					
Total Alkalinity		Calcium Hardness		Temperature	
A-Factor		C-Factor		T-Factor	
PPM	Factor Value	PPM	Factor Value	°F	Factor Value
5	= 0.7	5	= 0.9	32	= 0.0
25	= 1.4	25	= 1.0	37	= 0.1
50	= 1.7	50	= 1.3	46	= 0.2
75	= 1.9	75	= 1.5	53	= 0.3
100	= 2.0	100	= 1.6	60	= 0.4
150	= 2.2	150	= 1.8	66	= 0.5
200	= 2.3	200	= 1.9	76	= 0.6
300	= 2.5	300	= 2.1	84	= 0.7
400	= 2.6	400	= 2.2	94	= 0.8
800	= 2.9	800	= 2.5	105	= 0.9
A saturation index of 0 is perfectly balanced A negative saturation index has corrosive tendencies A positive saturation index has scaling tendencies A saturation index of +0.3 or -0.3 is ideal * -12.1 should be changed to -12.2 if Total Dissolved Solids (TDS) measure at 1,000 ppm or greater					

Table 8. Water Saturation Index

The practice of putting tablet-based sanitizer in the skimmer basket can produce heavily chlorinated water with very low pH. If this comes in contact with metal parts of the heater it can cause serious damage. Practices like this should be discontinued.

If acidic conditions are present, there could be signs of metal in the pool water that could cause staining on the floor of your pool. This might manifest itself in the form of brown stains on the finish of your pool bottom or pool water discoloration. Your local pool dealer can test for metals in your water or can provide you with a test kit.

Every effort should be made to maintain the water balance of your pool or spa in the proper range. Ignoring this very important component of your pool's water chemistry can make the water less enjoyable to bathe in and result in permanent damage to your heater and/or complete failure of individual components.

Zodiac Pool Systems LLC does not warrant heat exchangers damaged by corrosive water issues or from the build-up of calcium in the heater's heat exchanger. Any questions regarding proper water balance can be directed to our product support line at Zodiac® or to your local pool dealer.

NOTE: The Thermal Regulator Valve (TRV) is an indicator of how well the water balance is being maintained. The TRV should be inspected before each pool season to ensure it is clean and operating properly. If you see signs of calcium buildup (scale-forming or base water) or corrosion (acidic water) the TRV should be replaced and your water balanced.

10.2 Swimming Pool Energy Saving Tips

Please review the following recommendations to help conserve fuel and minimize the cost of operating your pool heater without sacrificing comfort.

- The American Red Cross® recommends a maximum water temperature of 78°F (26°C). Use an accurate pool thermometer. A difference of 4°F (2°C), between 78°F and 82°F (26°C and 28°C), will use as much as 40% more gas.
- Carefully monitor the water temperature of your pool in the summertime. You can reduce heater usage due to warmer air temperatures.
- Find the proper setting on the pool heater temperature control and use the Set Point Lockout feature to discourage further adjustments.
- Set the pump time clock to start the pump no earlier than 6:00 AM. This is the time when nightly heat loss balances.
- If the pool is only going to be used on weekends, reduce the heater temperature control setting by 8 or 10 degrees during the week. Reset it to the 78°F (26°C) level a day or so before you plan to use the pool.
- During the winter or when on vacation for longer than a week, shut down the heater by following the shutdown instructions found in Section 9.6, *Performing Seasonal Shutdown and Lighting and Shutdown Instructions label on top panel and on the inside of the heater.*
- Where possible, shelter the pool from prevailing winds with well-trimmed hedges or other landscaping, cabanas, or fencing.
- The greatest source of heat loss in a swimming pool is through evaporation. It can account for 50% of pool systems total heat loss. The use of solar blankets, automatic covers or anything that limits the air's access to the surface of the water will help reduce this heat loss and minimize evaporation.

10.3 Winterizing

In areas where freezing temperatures occur in winter and the pool or spa will not be used, the pool should be winterized by a qualified pool service technician:

- Turn off the electrical supply and the main gas supply to the heater.
- Remove the heater access panel.
- Turn off gas supply to the heater following the shut-down instructions. See Section 9.6, *Performing Seasonal Shutdown, and Lighting and Shutdown Instructions label on top panel.*
- Remove the drain plug/outlet temperature sensor from the inlet/outlet header and completely drain the heater before the first frost. See Section 5.6.1, *Install Pressure Relief Valve Kit #R0336101 step "a".*
- Inspect the gasket on the drain plug/outlet temperature sensor. Store the drain plug/outlet temperature sensor in a safe place for winter.
- Cover the exhaust vent grill with plastic so that snow will not accumulate and freeze on top of the combustion chamber.

- Remove and drain the copper tubing (siphon loop) for the water pressure switch.




Figure 34. Water Pressure Switch Copper Tubing (Siphon Loop)

10.4 Spring Start-up

When winterized, the heater should be reassembled by a qualified professional technician in the Spring.

- Reinstall the drain plug/outlet temperature sensor.
- Uncover the vent grill.
- Reattach copper tubing to water pressure switch.
- Make sure power is supplied to the pump.
- Turn on the filter pump and circulate water through the heater for 5 minutes. Check for leaks while circulating.
- Turn on the main gas supply to the heater at the gas valve outside the heater jacket.
- Turn on the heater according to Section 8.6, *Performing Seasonal Shutdown, and Lighting and Shutdown Instructions label on top panel.*

10.5 Inspection and Service

⚠ WARNING

Improper installation or maintenance can cause nausea or asphyxiation from carbon monoxide in flue gases which could result in severe injury, or death.

For your safety, when starting the heater, keep your head and face away from any exhaust or inlet grill openings to prevent any risk of personal injury. Make sure all doors/panels are securely in place and stand back from the heater.

The heater is designed and constructed to provide long performance life when installed and operated properly under normal conditions. Periodic inspections, especially at spring start-up, are important to keep your heater running safely and efficiently through the years. Zodiac Pool Systems LLC recommends that the homeowner inspect the heater on a regular basis (especially after abnormal weather conditions), and arrange to have a professional inspection at least once a year by a qualified service technician.

10.5.1 Guidelines for Homeowner Inspection

⚠ WARNING

Do not store or use gasoline or other flammable vapors, liquids or chemicals in the vicinity of this or any other appliance.

Do not use this heater if any part has been under water. Immediately call a qualified service technician to inspect the heater and replace any part of the control system and any gas control which has been under water.

To reduce the risk of fire, install pool equipment in an area where leaves or other debris will not collect on or around the equipment. Keep surrounding area clear of all debris such as paper, leaves, pine-needles and other combustible materials.

- Ensure the top of the heater, under the heater, and surrounding area clear of all debris and combustible materials such as paper, leaves, etc.
- If there is a pressure relief valve, check for corrosion in and around the valve. If there is corrosion, contact a pool professional for replacement of the pressure relief valve.
- Once a year check that water is running freely through the pressure relief valve. To check, turn on the filter pump and lift the release lever on the top of the valve.
- Be sure combustion air and ventilation openings are not blocked.

10.5.2 Guidelines for Professional Inspection

The following inspections should be made once a year or as needed. Routine inspections are a critical to the safety and long life of your Jandy pool equipment.

- Check for loose or broken wires and terminal connections.
- Check the water pressure switch by turning the filter pump off and on several times. The burner should go off immediately after the pump stops. The fan will run for 45 seconds after the burner shuts down.

⚠ CAUTION

If the heater is wired serially to or on the same relay as the filter pump, there is a chance that power will be disconnected to the heater before the fan is able to fully purge the combustion chamber. It is inadvisable to install the heater in a manner which would prevent this combustion chamber purge from taking place.

- An ignition sequence should start shortly after the pump is turned back on.
- Inspect the thermal regulator valve (TRV).
- Inspect the electrical controls, specifically:
 - High limit switches
 - Water pressure switch
 - Automatic gas valve
 - Power interface/Temperature control
 - Flue temperature sensor
 - Control circuit fuse
 - Ignition control
 - Air pressure switch
 - Inlet water temperature sensor
 - Heater exchanger outlet water temperature sensor
 - Gas pressure switch
- Inspect the inlet grill at the blower for blockage, leakage, and corrosion.
- Inspect the combustion blower for damage.
- Conduct a normal operating cycle and observe that the sequence proceeds as intended.
- If the heater is equipped with a pressure relief valve, clean any accumulated corrosion and make sure that water runs freely when lever is lifted.
- Inspect combustion chamber and blower exterior for corrosion and indication of improper operation.
- Inspect electrical controls for deterioration. Repair and replace as necessary.
- Visually check the main burner flame. Remove the top of the heater to inspect the sight glass. See Figure 35.




Figure 35. Remove Heater Top to View Sight Glass

Section 11. Troubleshooting

11.1 Common Problems

Zodiac Pool Systems LLC strongly recommends that you call a qualified service technician to perform all service and repairs on the heater. To locate a licensed or qualified technician or service company, call Jandy Technical Support at 1.800.822.7933, or visit www.jandy.com.

The following table lists some of the most common problems when running the heater. Most problems occur when the heater is started for the first time after installation or at spring start-up.

Symptom	Possible Cause	Remedy
Pump not operating	No power. Pump defective. Incorrectly wired. Time clock settings not synchronized with actual time.	Check circuit breakers and power source. Replace the pump. Recheck wiring. Check time clock setting.
Unstable combustion (1) heater turns off and on (2) heater ignites slowly (3) flame lifts and goes out (4) short yellow streaked flame	Wrong gas. Lean fuel/air mixture — low supply pressure. Lean fuel/air mixture — too much combustion air. Rich fuel/air mixture — high manifold pressure. Rich fuel/air mixture — too little combustion air.	Make sure the gas supply matches the gas type indicated on the rating plate. Correct gas supply inlet pressure to: - (NATURAL GAS) 4.0 in W.C. min - 10.5 in W.C. max - (PROPANE) 4.0 in W.C. min - 14.0 in W.C. max Offset pressure should be -0.2 in W.C. Use a digital differential manometer to verify correct offset pressure. Adjust offset pressure as needed. Connect a digital differential manometer to blower throat and gas valve port to obtain differential. Make sure the differential value falls within the specified range for the heater size. Perform an amp draw test on one of the blower power supply wires. Compare reading to data plate for specific range based on WAC and Hz. When amp draw is high, low cfm in mixture to burner. Gas meter too small. Gas line from meter to heater too small. Check blower inlet grill for obstruction.

Symptom	Possible Cause	Remedy
Not enough heat (1) heater is slow to heat up (2) heater not maintaining set temperature (3) Low temperature rise	Heater size inadequate. Filter pump not running long enough. Thermal regulator valve (TRV) is opening early or is permanently open. Heater plumbed backwards.	Confirm adequate gas supply volume, then replace with heater of higher output. Replace TRV. Heater is condensing. Flue product moisture will condense at the start-up until the heater water temperature reaches the normal operating conditions. Correct the plumbing.
Heater pounding or knocking	Water flow through heater too low. Failed Thermal Regulating Valve (TRV).	Look for obstruction or closed valve in system. Check for damaged internal bypass. Variable speed pump set too low. Dirty filter or baskets.
Igniter lights but heater does not fire	Gas valve is not ON. Air in gas line. No power to gas valve. Low gas pressure/volume. High burner throat pressure. Gas valve failed.	Flip the switch on the gas valve to the "on" position. Cycle ignition sequence until air is out of the gas line. Check controls for proper operation. Check supply pressure/volume and verify proper gas supply pipe size. Replace gas valve. NOTE: Gas valve failures are extremely rare. Please confirm this as the root problem before replacing.

11.2 Service Diagnostic Messages

The controller monitors several functions of the heater. In the event of a malfunction, the controller will display a **FAULT** message. The following table lists the Heater Service Messages along with potential causes and remedies.

Fault Code	Possible Cause	Recommendations
REPLACE MAIN BOARD	Fault detected in internal circuitry of main board.	Replace the main board.
CHECK H2O FLOW	Pump is not running. Low pump pressure. Pressure switch fault. Variable speed pump set too low.	Check breakers and power source, recheck wiring, set time clock and current time. Clean filter or clear blockage, check position of valve in plumbing system. Make sure return eyeball fittings are installed on the wall of the pool. Adjust or replace pressure switch. Adjust variable speed pump. Refer to qualified service personnel.
CHECK AUX MONITOR	The AUX switch is reading open when it should be closed.	Check aux switch is connected properly. If no peripheral switch is present make sure a jumper is in place.
CHECK VERSAFLO	VersaFlo™ diverter gate isn't registering in the proper position.	Check for debris or mechanical obstruction. Can you move the actuator open and close freely by hand? Verify the diverter gate microswitch operation.
CHECK LOUVER	If this feature is enabled, it means the louver isn't registering in the proper position.	If feature is NOT being used: • Ensure there is a jumper wire on the contact • The feature has been disabled in the menu If feature is being used: • Check for mechanical obstruction • Power to the louver motor • Verify microswitch operation for louver

Fault Code	Possible Cause	Recommendations
CHK IN H2O SENSOR	Inlet water sensor is reading as either an open or short condition.	Verify resistance reading of thermistor - replace if bad. Check wiring and condition of thermistor.
HI INLET H2O TEMP	Inlet water sensor reading > 106°F while the water pressure switch satisfied.	Verify resistance reading of thermistor - replace if bad. Verify water temp at heater (especially if a remote sensor is used). Verify plumbing to the heater is correct.
HIGH LIMIT SWITCH	Open circuit with one of the high limit switches.	Check for anything that could obstruct or limit water flow to the heat exchanger (TRV and spring bypass in the header or heavy obstruction in the heat exchanger tubes). Check operation of high limit switches - replace, if bad.
CHECK FLUE SENSOR	Flue sensor is reading as either an open or short condition.	Verify resistance reading of thermistor - replace if bad. Check wiring and condition of thermistor.
CHK PWR GAS VALVE	The board is not sending power to the gas valve.	Replace ignition controller board.
LOW GAS PRESSURE	Gas pressure switch is not satisfied. Confirm that the gas pressure is within the specifications as set forth in <i>Section 4.2, Inlet Gas Pressure Test</i> . It may be necessary to contact your gas provider. Inadequate gas delivery systems are typically upgraded by the utility at no charge to homeowners.	Verify that you have adequate gas supply pressure. Verify gas pressure switch operation.
CHK OUT H2O SENSOR	Outlet water sensor is reading as either an open or short condition.	Verify resistance reading of thermistor - replace if bad. Check wiring and condition of thermistor.
TEMP RISE LOW	Temp rise across the heat exchanger is below the lower limit.	Check if water flow is too high. Sooting of heat exchanger (should show high flue temps as well). Improper installation.
UNEXPECTED FLAME	Sensing a flame while there is no call for heat.	Replace integrated control board.
TEMP RISE HIGH	Temp rise across the heat exchanger is above the upper limit.	Check if water flow is too low. TRV is stuck closed. Heavy restriction in water flow to heat exchanger.
CHK HEAT EXCHANGER	Flue temperature in excess of 400° for > 5 minutes.	Check for sooting on outside of heat exchanger tubes or anything that can inhibit water flow through the heat exchanger which can also cause other error codes to appear. Check for scale or debris build up inside tubes or header. Check TRV and spring bypass in header (a TRV that doesn't open or a bypass stuck open can cause issues). Verify proper water flow (can run self diagnostic with temp rise).
CHECK H2O WIRING	Inlet water temp reading 5°F or greater above outlet water temp while running.	Check if the water sensor connections are reversed at the ignition control board.
CHECK FLUE WIRING	Flue sensor reading < 200° with a water sensor reading > 200° while the heater is running.	Check if a water sensor and flue sensor connection is reversed at the ignition control board.
L/N WIRES REVERSED	If wired for 120V and the Neutral connection is over 70VAC greater than the 24VAC common line.	Check if the L/N connections are reversed.

Fault Code	Possible Cause	Recommendations
FLAME SIGNAL FAIL	No flame signal detected while running. A flame strength signal of less than 0.5 microamps while the heater is running will issue this fault code.	Check igniter (cold ohms resistance of 30-800 ohms at 75F (+/- 10F) temp or microamp signal in service diagnostic). Verify there is no flame (sight glass). Run service diagnostic or look for faults (i.e. air pressure switch). Verify operation of gas valve and blower.
NO GND CONNECTION	Ignition control pcb is not connected to the supply ground.	Check ground connections.
FLAME SIGNAL WEAK	Sensed flame signal is less than 1.5 microamps for > 10 secs.	Check igniter (30-800 ohms at 75F (+/- 10F) for cold ohms resistance and visual) - replace if suspect. Confirm inlet gas pressure is within range while gas valve is open. Check for strong flame through sight glass.
CHECK AIR FLOW	Power sent to blower but air switch is open.	Confirm air pressure switch operation and wiring connections. Look for blockage in the vent or incoming air.
CHECK AIR SWITCH	An internal check feature within the ignition control board has failed. Check air pressure switch. It should be normally open when the blower is off.	Replace board. Check air pressure switch, it should be normally open when the blower is off.
HIGH FLUE TEMP	Flue temperature > 464°	Contact a qualified service professional. Verify good water flow to heater. Check condition of heat exchanger (heavy sooting or scaling).
IGNITION CONTROL LOCKOUT	3 failed attempts at ignition during a given heat demand cycle.	Check fault code history and run service diagnostic (3 failed ignition attempts during one heat demand cycle will lock out the heater).

11.3 Ignition Control LED Service Codes

The LEDs on the ignition controller are used to provide updates on the status of the controller. See the table below for descriptions of the status LEDs.

LED Description	Status Description
LED 1 blinking	Input power present
LED 2 blinking	Communicating via RS485
LED 3 blinking	Communicating with the UI




Figure 36. LED Locations

Section 12. Professional Service and Maintenance

⚠ WARNING

SERVICING SAFETY

Service procedures can be hazardous because they involve fuel gas, electricity, moving parts and procedures which require testing or temporary bypass of safety controls. For this reason, the heater must be serviced only by a qualified professional service technician.

IMPROPER SERVICE HAZARD

The heater incorporates unique design features. Incorrect service of this heater can result in personal injury or damage to property. To avoid such hazards, the heater must be serviced only by a qualified professional service technician.

Call a qualified service technician to perform all service and repairs on the heater. To locate a licensed or qualified technician or independent service company in your area, contact Zodiac Technical Support at:

1.800.822.7933 | www.jandy.com

Before servicing the heater:

- Confirm that the heater control is set to either POOL or SPA.
- Confirm the temperature set point for either Pool or Spa is set high enough to make the heater operate given the current water temperature.

12.1 Header Bypass Reassembly Recommendations

If you need to remove the access cover or the VersaFlo™ housing from the header, use the following torque process to re-install them to the header. Start each screw by hand and then follow the torque pattern detailed in Figure 37. Do NOT use a cordless drill or impact driver to set screws into the plastic header.




Figure 37. Header Bypass Reassembly Torque Pattern

Section 13. Spare Parts


Using genuine Zodiac factory replacement parts helps to ensure the ongoing quality and reliability of our products.

Unauthentic parts might seem okay on the surface, but they often fall short of factory standards, and they typically lack the backing you get from an established, global manufacturer like Zodiac. Plus, the use of unauthentic parts may void all factory warranties.

Zodiac does not sell parts directly to pool owners, so when it's time for maintenance, please see your local Preferred Professional Provider (PPP) of genuine parts. You can find a PPP at www.zodiacpoolsystems.com/parts.

NOTE: To identify the correct part, you will need to know the model number, serial number and type of gas when applicable. This information can be found on the rating plate sticker, which is located inside the heater on the outside of the combustion chamber.

13.1 Major Components




13.2 Cabinet Assembly Spare Parts List and Exploded Parts Diagram

For ASME compliant heater models JXIQ400NC, JXIQ400PC, JXIQ260NC and JXIQ260PC please see Section 14, Appendix A. ASME® Compliant Header.

Key No.	Description	Model 200	Model 260	Model 400
1	Heater Jacket Top Kit (no User Interface)	R0592400	R0592400	R0592400
2	Corner Post Kit, Left/Right (set of 2)	R0592500	R0592500	R0592500
3	Heater Base Kit	R0592600	R0592600	R0592600
4	Front or Back Panel Kit	R0592700	R0592700	R0592700
5*	Side Panel Kit	R0592900	R0592900	R0592900
6	Vent Terminal Housing Kit	R0593100	R0593100	R0593100
7	Jacket Hardware Kit	R0593300	R0593300	R0593300
8	Anchor Brackets Kit (set of 4)	R0593400	R0593400	R0593400
9	Jacket Hole Plug Kit	R0591800	R0591800	R0591800
10**	Complete Replacement Box Packaging Kit	R0593600	R0593600	R0593600
11	Bonding Lug	R0852800	R0852800	R0852800

*Includes: Exhaust side panel, top panel closure, anti rotation bracket and access door. Header side panel LH, Header side panel RH.

** Not Shown



13.3 Heat System Spare Parts List and Exploded Parts Diagrams


The following JXIQ Models are equipped with a Cupronickel (CuNi) heat exchanger.

- JXIQ400NN, JXIQ400PN

13.3.1 Combustion Chamber Assembly

For ASME compliant heater models JXIQ400NC, JXIQ400PC, JXIQ260NC and JXIQ260PC please see [Section 14, Appendix A. ASME® Compliant Header](#).


Key No	Description	Model 200	Model 260	Model 400	Model 400 CuNi
1	Exhaust Elbow Assembly Kit	R0590200	R0590200	R0590200	R0590200
2	Band Clamp Kit	R0590400	R0590400	R0590400	R0590400
3	Refractory Kit, Internal	R0590500	R0590500	R0590500	R0590500
4	Combustion Chamber Shelf (set of 2: Models 200, 260)	R0590700	R0590700	N/A	N/A
5	Combustion Chamber Lid Kit	R0590800	R0590800	R0590800	R0590800
6	Gasket Kit	R0590900	R0590900	R0590900	R0590900
7	Sight Glass Kit	R0305400	R0305400	R0305400	R0305400
8	Igniter Kit	R0457502	R0457502	R0457502	R0457502
9	Insulation Kit, External	R0591000	R0591000	R0591000	R0591000
10	Isolator Kit (Thermal)	R0593200	R0593200	R0593200	R0593200
11	Heat Exchange Assembly	R0589402	R0589403	R0589405	R0746905
12	Combustion Chamber Assembly (includes Header)	N/A	R0988203	R0988205	N/A



13.3.2 Burner Assembly

Key No	Description	Model 200		Model 260		Model 400	
		*N	**LP	N	LP	N	LP
1	Blower Assembly Kit	R0591100	R0591100	R0591100	R0591100	R0591100	R0591100
2	Air Intake Grate Kit	R0591200	R0591200	R0591200	R0591200	R0591200	R0591200
3	Blower Intake Orifice Kit	R0591302	R0591312	R0591303	R0591313	R0591305	R0591315
4	Fuel Orifice Kit	R0591601	R0591605	R0591602	R0591606	R0591604	R0591608
5	Gas Valve Assembly Kit	R0591400	R0591400	R0591400	R0591400	R0591400	R0591400
6	Burner Kit	R0591702	R0591702	R0591703	R0591703	R0591705	R0591705
7	Capacitor Kit	R0614500	R0614500	R0614500	R0614500	R0614500	R0614500
8	Gas Pressure Switch	R0989100	R0989100	R0989100	R0989100	R0989100	R0989100
9	Gas Pressure Switch Assembly	R0988500	R0988500	R0988500	R0988500	R0988500	R0988500

* N - Natural Gas **LP - Liquid Propane




13.4 Water System Spare Parts List and Exploded Parts Diagrams

For ASME compliant heater models JXIQ400NC, JXIQ400PC, JXIQ260NC and JXIQ260PC please see Section 14, Appendix A, ASME® Compliant Header.


Key No	Description	Model 200	Model 260	Model 400
1	Access Door Kit (with O-Ring Seal and Screws)	R0589600	R0589600	R0589600
1a	VersaFlo™ Bypass (Optional Accessory)	JXMFKIT	JXMFKIT	JXMFKIT
2	Thermal Regulator Valve Kit (TRV)	R0589701	R0589701	R0589701
3	Bypass Kit	R0589800	R0589800	R0589800
4	Drain plug/outlet temperature sensor Kit	R0988600	R0988600	R0988600
5	Gasket and Seals Kit	R0589500	R0589500	R0589500
6	Manifold Backplate Kit	R0590002	R0590003	R0590005
7	Manifold, 3 Port (no backplate included; must order separately)	R0590100	R0590100	R0590100
8	Water Pressure Switch Kit	R0457001	R0457001	R0457001
9	Goody Bag Kit†	R0593500	R0593500	R0593500
10	Universal Half Union Kit (1 Ea. requires 2 Kits for full unit replacement)	R0522900	R0522900	R0522900
11	Sweep Elbow AquaLink® Temp Sensor	SEAQL1001	SEAQL1001	SEAQL1001
12	Drain Cap Assembly Kit	R0523000	R0523000	R0523000
13	Pressure Relief Valve (PRV) Install Kit	R0336101	R0336101	R0336101
14	Flow Plate Assembly	R0725201	R0725202	R0725203
15	Sacrificial Anode	R0965100	R0965100	R0965100

† Goody Bag Kit Also Includes the Installation and Operation Manual and the Universal Controller Quick Guide



13.5 Electrical System Spare Parts List and Exploded Parts Diagrams

Key No	Description	Model 200	Model 260	Model 400
1	Transformer Kit	R0456301	R0456301	R0456301
2	User Interface Kit	R0988800	R0988800	R0988800
3	User Interface Lid Kit	R0989200	R0989200	R0989200
4	Wiring Harness Kit	R0988900	R0988900	R0988900
5	Air Pressure Switch Kit	R0456400	R0456400	R0456400
6	Flue Temp Sensor(s)	R0719402	R0719402	R0719402
7	Water Pressure Switch Kit	R0013203	R0013203	R0013203
8	Ignition Controller Board	R0988700	R0988700	R0988700
9	Inlet Water Temperature Sensor Kit	R0456502	R0456502	R0456502
10	High Limit Temperature Sensors Kit	R0592300	R0592300	R0592300
11	Igniter Kit	R0457502	R0457502	R0457502
12	Power Interface Harness	R0985500	R0985500	R0985500
13	User interface lock box kit	JXIGUARD	JXIGUARD	JXIGUARD
	Fuse Kit	R1009500	R1009500	R1009500



Section 14. Appendix A. ASME® Compliant Header

Please use the information below for the following ASME compliant heater Models, JXIQ400NC, JXIQ400NS, JXIQ400PC, JXIQ400PS, JXIQ260NC, JXIQ260NS, JXIQ260PC and JXIQ260PS. The corresponding sections from the manual are cross referenced at the beginning of each section.

14.1 Dimensions

(From Section 1.5, Dimensions at front of manual)




Figure 38. General Dimensions

14.2 Package Contents

(From Section 2.1, Package Contents at front of manual)

Before completely unpacking the unit please inspect carton for damage. In addition, please check the carton label to ensure that you have the correct fuel type and BTU rating for your application.

Included with this heater is a 75 psi pressure relief valve that can be used as an option. Instructions for the pressure relief valve installation are shown below in Section 5.6.1, Install Pressure Relief Valve Kit #R0336101.



Item	Description	Qty.
1	JXIQ Heater	1
2	Connector Flange	2
3	2" Sleeve	2
4	2" Gasket	2
5	Flange Bolt	4
6	Flange Washer	4
7	75 psi Pressure Relief Valve Kit	1



14.3 Pump Sizing

(From Section 5.1, Pump Sizing at front of manual)

All JXIQ heaters utilize an internal bypass mechanism and thermal regulator valve (TRV) to accommodate flow rates delivered to the heater from a minimum of 30 gallons per minute (gpm) to a maximum flow of 100 gpm.

⚠ CAUTION

The system water pump must be capable of providing no less than 30 gpm of flow through the heater. Flow rates at less than 30 gpm may cause nuisance operation causing damage to the heater or causing the heater to turn off.

Model	Min gpm (lpm)	Max gpm (lpm)
JXIQ 260	30 (114)	100 (379)
JXIQ 400	30 (114)	100 (379)

Table 9. Recommended Flow Rate Adjustment




Figure 39. Head Loss Chart

14.3.1 Water Inlet Piping

(From Section 5.2.2, Water Inlet Piping at front of manual)

Check flow rates as outlined in Section 5.1, Pump Sizing and if necessary make provisions for and ensure sufficient space for the installation of a manual bypass valve as outlined in Section 5.1.1, Manual Bypass Valve.

The side inlet is positioned at a 10 1/8 in (255.7 cm) center height providing an ideal height for replacement unit or new construction plumbing.

- Turn off all power to the heater at the breaker.
- Turn off main gas supply to heater.
- Make sure the pump is off and will remain off for the duration of the procedure.

- Do a dry fit test of cut pipe lengths in order to ensure proper alignment.
- Pass the 2" sleeve through the 2" gasket.
- Seat the gasket and sleeve into the connector flange.
- Secure the connector flange to the header using the flange bolts and washers. Make sure that the gasket is properly seated at the header.
- Install 2" threaded pipe into the connector flange.
- Repeat the above steps for the manifold outlet. Again paying special care to ensure proper seating of the gasket.

NOTE: When connecting CPVC pipe to the metal receptacle, Zodiac Pool Systems LLC recommends LA-CO® PLASTO-JOINT STIK® joint Compound.




Figure 40. 2" Threaded Inlet Pipe

- Return all valves to their operating positions.
- Restore power to the heater at the breaker.
- Turn on pump and inspect carefully for leaks.
- Restore main gas supply.
- Start the system and check for proper flow.
- Return heater to normal operation.

⚠ WARNING



Never approach, inspect or attempt to troubleshoot any leaking valves or plumbing without turning off all electrical power to the system. Failure to turn off all electrical power can result in electrical shock, serious injury or death. Ensure that all electrical power to the system is turned off before approaching, inspecting or troubleshooting any leaking valves or plumbing that may have caused other electrical devices in the surrounding area to get wet.

⚠ WARNING



Follow all filter manufacturer's instructions. Never attempt to assemble, disassemble or adjust the filter when there is pressurized air in the system. Starting the pump while there is any pressurized air in the system can cause the filter lid to be blown off, which can cause death, serious personal injury or property damage.

14.3.2 Install Pressure Relief Valve kit #R0336102


Please double check that you have all necessary parts to complete the installation. If any parts are missing or damaged please call 1.800.822.7933 for assistance.



Item	Description	Bronze Header
1	Pressure Relief Valve 3/4" X 3/4" 75 PSI	X
2	Brass Nipple 3/4"	X
3	Elbow 90° 3/4" NPT Brass	X
4	Teflon™ Tape	X


Prior to installing or replacing this pressure relieve valve (PRV), ensure the following steps have been completed.

- Turn off the electrical power to the heater.
- Turn off the main gas supply to the heater.
- If the heater has been operating, ensure you allow enough time for remaining water in the heat exchanger to cool down before beginning. It is recommended that protective gloves be worn during the entire procedure.
- Make sure the filter pump is off and will remain off for the duration of the installation procedure.
- If the heater is below the surface level of the water in the pool or spa, close all shut-off valves between the heater and the pool.




- Remove drain plug/outlet temperature sensor from header and allow all water to drain from heat exchanger.
- Remove the port plug on Thermal Regulating Valve access plate.
- Each male connection should be first wrapped in 5-6 turns of Teflon™ tape.
- Assemble the 3/4" threaded nipple and elbow. Make sure to get a snug fit. Do not over tighten.

- Install the nipple and elbow assembly at the access plate port.
- Install the pressure relief valve. Make sure to get a snug fit. Do not over tighten. The final orientation of the pressure relief valve should be vertically aligned with the discharge opening facing away from the heater header.



- Install a discharge pipe from the pressure relief valve discharge opening to a safe area. This is a precaution to prevent the possibility of personal injury or property damage in the event scalding water is discharged from the pressure relief valve.
- Install the discharge pipe so that there is no trapped or standing water in the piping. Discharge piping must be facing down, terminating with a threadless nipple, no more than 6 in (152 mm) and no less than twice the diameter of the discharge pipe from the floor or drain/receptor.



To ensure the continued proper operation of the pressure relief valve, the valve should be tested once a year. To test, lift the lever with the circulation system running to ensure that water will pass through. When the lever is down, there should be no leaks from the outlet.


14.4 Cabinet Assembly Spare Parts List and Exploded Parts Diagram

(From Section 13.2, Cabinet Assembly Spare Parts List and Exploded Parts Diagram)

Key No.	Description	Model 200	Model 400
1	Heater Jacket Top Kit (no User Interface)	R0592400	R0592400
2	Corner Post Kit, Left/Right (set of 2)	R0592500	R0592500
3	Heater Base Kit	R0592600	R0592600
4	Front or Back Panel Kit	R0592702	R0592702
5*	Side Panel Kit	R0821001	R0821001
6	Vent Terminal Housing Kit	R0593100	R0593100
7	Jacket Hardware Kit	R0593300	R0593300
8	Anchor Brackets Kit (set of 4)	R0593400	R0593400
9	Jacket Hole Plug Kit	R0591800	R0591800
10**	Complete Replacement Box Packaging Kit	R0593600	R0593600
11	Bonding Lug	R0852800	R0852800

*Includes: Exhaust side panel, top panel closure, air filter bracket and access door.
Header side panel LH, Header side panel RH.


** Not Shown in Exploded View



14.4.1 Combustion Chamber Assembly

(From Section 13.3.1, Combustion Chamber Assembly)

Key No	Description	Model 260	Model 400
1	Exhaust Elbow Assembly Kit	R0590200	R0590200
2	Band Clamp Kit	R0590400	R0590400
3	Refractory Kit, Internal	R0590600	R0590500
4	Combustion Chamber Shelf (set of 2: Models 200, 260)	R0590700	N/A
5	Combustion Chamber Lid Kit	R0590800	R0590800
6	Gasket Kit	R0590900	R0590900
7	Sight Glass Kit	R0305400	R0305400
8	Igniter Kit	R0457502	R0457502
9	Insulation Kit, External	R0591000	R0591000
10	Isolator Kit (Thermal)	R0593200	R0593200
11	ASME Combustion Chamber Assembly (includes Header)	R0988303	R0988305
11a	Combustion Chamber Assembly, ASME Compliant CuNi versions (includes Header)	R0988403	R0988405
12	ASME Heat Exchanger Kit	R0828700	R0828701
12a	Heat Exchanger Kit, ASME Compliant CuNi versions	R0961100	R0961101



14.5 Water System Spare Parts List and Exploded Parts Diagrams

(From Section 13.4, *Water System Spare Parts List and Exploded Parts Diagrams*)

Key No.	Description	Model 260	Model 400
1	Thermal Regulator Valve Access Plate Kit	R0820400	R0820400
2	Thermal Regulator Valve Kit (TRV)	R0589701	R0589701
3	Thermal Regulator Valve Retainer Kit	R0820500	R0820500
4	Bypass Kit	R0589800	R0589800
5	Drain plug/outlet temperature sensor Kit	R0988600	R0988600
6	Gasket and Seals Kit	R0820700	R0820700
7	Header Backplate Kit	R0828403	R0828405
8	Header, 2 Port (no backplate included, must order separately)	R0820800	R0820800
9	Water Pressure Switch Kit	R0828501	R0828501
10	Pressure Relief Valve (PRV) Install Kit	R0336102	R0336102
11	Flow Plate Assembly	R0828602	R0828603
12	Connector Flange Kit	R0461500	R0461500
13	Connector Flange Hardware	R0477800	R0477800
14*	Goody Bag Kit (Goody Bag Kit includes the Installation and Operation Manual and the Universal Controller Quick Guide)	R0820900	R0820900

*Not Shown in Exploded View

