


# OLMO

SINGLE-ZONE

## **SIERRA** SERIES

WALL MOUNTED MINI SPLIT AIR CONDITIONING SYSTEM

## Installation Manual



### Models:

OS-09SRW-115VI  
OS-SR09-115VO  
OS-12SRW-115VI  
OS-SR12-115VO  
OS-09SRW-230VI  
OS-SR09-230VO  
OS-12SRW-230VI  
OS-SR12-230VO  
OS-18SRW-230VI  
OS-SR18-230VO  
OS-24SRW-230VI  
OS-SR24-230VO  
OS-36SRW-230VI  
OS-SR36-230VO

### IMPORTANT NOTE:

Thank you for purchasing our air conditioning system. Please read this manual carefully before operating your new air conditioning units. Make sure to save this manual for future reference.

# Contents

---

|                                  |    |
|----------------------------------|----|
| <b>Safety Instructions</b>       | 1  |
| <b>Preparation before Use</b>    | 3  |
| Preset                           | 3  |
| Safeguarding the Environment     | 3  |
| <b>Safety Precautions</b>        | 4  |
| <b>Installation Instructions</b> | 14 |
| Suggested Tools                  | 14 |
| Installation Diagram             | 15 |
| Site Instructions                | 16 |
| Indoor Unit Installation         | 17 |
| Outdoor Unit Installation        | 23 |
| Power and Wiring                 | 25 |
| Wiring Diagram                   | 26 |
| Vacuum Testing and Charging      | 26 |
| Start-up                         | 27 |
| <b>Care and Maintenance</b>      | 28 |
| <b>Protection</b>                | 29 |
| <b>Energy Saving Tips</b>        | 30 |
| <b>Troubleshooting</b>           | 31 |
| <b>Display Introduction</b>      | 32 |

*Remote controller operating instructions. See "remote controller instructions".*

# Safety Instructions

- 1. To guarantee the unit work normally, please read the manual carefully before installation, and try to install strictly according to this manual.
- 2. Do not let air enter the refrigeration system or discharge refrigerant when moving the air conditioner.
- 3. Properly ground the air conditioner into the earth.
- 4. Check the connecting cables and pipes carefully, make sure they are correct and firm before connecting the power of the air conditioner.
- 5. There must be an air-break switch.
- 6. After installing, the consumer must operate the air conditioner correctly according to this manual, keep a suitable storage for maintenance and moving of the air conditioner in the future.
- 7. The Fuse of the unit:

| Model            | Fuse of Indoor unit  | Fuse of outdoor unit |
|------------------|----------------------|----------------------|
| 9K(115V)         | T 3.15A or T 5A 250V | T 25A 250V           |
| 12K(115V)        | T 3.15A or T 5A 250V | T 25A 250V           |
| 9K-12K(208/230V) | T 3.15A or T 5A 250V | T 15A 250V           |
| 18K(208/230V)    | T 3.15A or T 5A 250V | T 20A 250V           |
| 24K(208/230V)    | T 3.15A or T 5A 250V | T 30A 250V           |
| 36K(208/230V)    | T 3.15A or T 5A 250V | T 30A 250V           |

- 8. A residual current device(RCD)with the rating of above 10mA shall be incorporated in the fixed wiring according to the national rule
- 9. Warning: Risk of electric shock can cause injury or death: Disconnect all remote electric power supplies before servicing .
- 10. The best length of the connecting pipe between the indoor unit and outdoor unit is less than 7.5 meters(24.6ft). It will affect the efficiency of the air conditioner if the distance longer than that length.
- 11. This appliance is not intended for use by persons (including children) with reduced physical, sensory or mental capabilities, or lack of experience and knowledge, unless they have been given supervision or instruction concerning use of the appliance by a person responsible for their safety.Children should be supervised to ensure that they do not play with the appliance.
- 12. This appliance can be used by children aged from 8 years and above and persons with reduced physical, sensory or mental capabilities or lack of experience and knowledge if they have been given supervision or instruction concerning use of the appliance in a safe way and understand the hazards involved. Children shall not play with the appliance. Cleaning and user maintenance shall not be made by children without supervision.
- 13. The batteries in remote controller must be recycled or disposed of properly. Disposal of Scrap Batteries --- Please discard the batteries as sorted municipal waste at the accessible collection point.

## Safety Instructions

- 14. If the appliance is fixed wiring, the appliance must be fitted with means for disconnection from the supply mains having a contact separation in all poles that provide full disconnection under overvoltage category III conditions, and these means must be incorporated in the fixed wiring in accordance with the wiring rules.
- 15. If the supply cord is damaged, it must be replaced by the manufacturer, its service agent or similarly qualified persons in order to avoid a hazard.
- 16. The appliance shall be installed in accordance with local electrical safety regulations and National Electrical Codes(NEC).
- 17. The air conditioner must be installed by professional or qualified persons.
- 18. The appliance shall not be installed in the laundry.
- 19. Regarding to installation, please refer to section "Installation instructions".
- 20. Regarding to maintenance, please refer to section "Care and Maintenance".
- 21. For models using R32 and R454B refrigerant, piping connection should be conducted on outdoor side.
- 22. When a flammable refrigerant is used, the requirements for installation or maintenance space of appliance is determined according to following:

| Minimum room area (m <sup>2</sup> /ft <sup>2</sup> ) |                          |             |            |            |            |
|------------------------------------------------------|--------------------------|-------------|------------|------------|------------|
| A <sub>min</sub> (m <sup>2</sup> /ft <sup>2</sup> )  | H <sub>inst</sub> (m/ft) |             |            |            |            |
| M <sub>c</sub> (kg/oz)                               | 1.8/5.9                  | 2.0/6.6     | 2.2/7.2    | 2.4/7.9    | 2.5/8.2    |
| 1.8/63.5                                             | 6.56/70.61               | 5.91/63.61  | 5.38/57.91 | 4.94/53.17 | 4.74/51.02 |
| 2.0/70.5                                             | 7.29/78.47               | 6.56/70.61  | 5.97/64.26 | 5.48/58.99 | 5.26/56.62 |
| 2.2/77.6                                             | 8.01/86.22               | 7.22/77.72  | 6.56/70.61 | 6.02/64.80 | 5.78/62.22 |
| 2.4/84.7                                             | 8.74/94.08               | 7.87/84.71  | 7.16/77.07 | 6.56/70.61 | 6.30/67.81 |
| 2.6/91.7                                             | 9.46/101.83              | 8.52/91.71  | 7.75/83.42 | 7.11/76.53 | 6.83/73.52 |
| 2.8/98.8                                             | 10.18/109.58             | 9.17/98.71  | 8.34/89.77 | 7.65/82.34 | 7.35/79.11 |
| 3.0/105.8                                            | 10.91/117.43             | 9.82/105.70 | 8.93/96.12 | 8.19/88.16 | 7.87/84.71 |

**NOTE:**

A<sub>min</sub> is the required minimum room area in m<sup>2</sup>/ft<sup>2</sup>  
 m<sub>c</sub> is the actual refrigerant charge in the system in kg/oz  
 h<sub>inst</sub> is the height of the bottom of the appliance relative to the floor of the room after installation in m/ft.

**WARNING:**

The minimum room area or minimum room area of conditioned space is based on releasable charge and total system refrigerant charge.

# Preparation before Use

## Note



- For the multi system, the refrigerant refer to the multi outdoor unit.
  - When charging refrigerant into the system, make sure to charge in liquid state, if the refrigerant of the appliance are R32 and R454B. Otherwise, chemical composition of refrigerant (R32 and R454B) inside the system may change and thus affect performance of the air conditioner.
  - According to the character of refrigerant (R32 and R454B, the value of GWP is 675 and 466), the pressure of the tube is very high, so be sure to be careful when you install and repair the appliance.
- 
- If the supply cord is damaged, it must be replaced by the manufacturer, its service agent or similarly qualified persons in order to avoid a hazard.
- 
- The air conditioner must be installed by trained, qualified installers and service mechanics.
- 
- The temperature of refrigerant circuit will be high, please keep the interconnection cable away from the copper tube.

## Preset

Before using the air conditioner, be sure to check and preset the following.

### • Remote Control Presetting

Each time after the remote control is replaced with new batteries or is energized, remote control auto presetting heat pump. If the air conditioner you purchased is a Cooling Only one, heat pump remote controller can also be used.

### • Back-light Function of Remote Control(optional)

Hold down any button on remote control to activate the back light. It automatically shuts off 3 seconds later.

**Note:** Back-light is an optional function.

### • Auto Restart Presetting

The air conditioner has an Auto-Restart function.

## Safeguarding the Environment

This appliance is made of recyclable or re-usable material. Scrapping must be carried out in compliance with local waste disposal regulations. Before scrapping it, make sure to cut off the mains cord so that the appliance cannot be re-used.

For more detailed information on handling and recycling this product, contact your local authorities who deal with the separate collection of rubbish or the shop where you bought the appliance.

### SCRAPPING OF APPLIANCE

This appliance is marked according to the European Directive 2012/19/EC, Waste Electrical and Electronic Equipment (WEEE).

This marking indicates that this product should not be disposed with other household wastes throughout the North America. To prevent possible harm to the environment or human health from uncontrolled waste disposal, recycle it responsibly to promote the sustainable reuse of material resources. To return your used device, please use the return and collection systems or contact the retailer where the product was purchased.

They can take this product for environmental safe recycling.



# Safety Precautions

Symbols in this Use and Care Manual are interpreted as shown below.



Be sure not to do.






Grounding is essential.



Pay attention to such a situation.



Warning: Incorrect handling could cause a serious hazard, such as death, serious injury, etc.

|                                                                                                                                                                                                                                                                                                                                                    |                                                                                                                                                                                                                                                                                                                                                                       |                                                                                                                                                                                                                                                                                                                           |
|----------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|-----------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|---------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
|  <p>Use correct power supply in accordance with the rating plate requirement. Otherwise, serious faults or hazard may occur or a fire maybe break out.</p>                                                                                                        |   <p>Keep the power supply circuit breaker or plug from dirt. Connect the power supply cord to it firmly and correctly, lest an electric shock or a fire break out due to insufficient contact.</p> |   <p>Do not use the power supply circuit breaker or pull off the plug to turn it off during operation. This may cause a fire due to spark, etc.</p> |
|   <p>Do not knit, pull or press the power supply cord, lest the power supply cord be broken. An electric shock or fire is probably caused by a broken power supply cord.</p> |   <p>Never insert a stick or similar obstacle to the unit. Since the fan rotates at high speed, this may cause an injury.</p>                                                                   |  <p>It is harmful to your health if the cool air reaches you for a long time. It is advisable to let the air flow be deflected to all the room.</p>                                                                                  |
|   <p>Turn off the appliance by remote control firstly before cutting off power supply if malfunction occurs.</p>                                                             |   <p>Do not repair the appliance by yourself. If this is done incorrectly, it may cause an electric shock, etc.</p>                                                                             |   <p>Prevent the air flow from reaching the gas burners and stove.</p>                                                                          |
|   <p>Do not touch the operation buttons when your hands are wet.</p>                                                                                                         |   <p>Do not put any objects on the outdoor unit.</p>                                                                                                                                            |   <p>It is the user's responsibility to make the appliance be grounded according to local codes or ordinances by a licenced technician.</p>     |

# Safety Precautions

## Precautions for using R32 and R454B refrigerant

For the multi system, the refrigerant refer to the multi outdoor unit. The basic installation work procedures are the same as the conventional refrigerant (R22 or R410A). However, pay attention to the following points:

### CAUTION

1. **Transport of equipment containing flammable refrigerants**  
Compliance with the transport regulations
2. **Marking of equipment using signs**  
Compliance with local regulations
3. **Disposal of equipment using flammable refrigerants**  
Compliance with national regulations
4. **Storage of equipment/appliances**  
The storage of equipment should be in accordance with the manufacturer's instructions.
5. **Storage of packed (unsold) equipment**
  - Storage package protection should be constructed such that mechanical damage to the equipment inside the package will not cause a leak of the refrigerant charge.
  - The maximum number of pieces of equipment permitted to be stored together will be determined by local regulations.
6. **Information on servicing**
  - 6-1 **Checks to the area**  
Prior to beginning work on systems containing flammable refrigerants, safety checks are necessary to ensure that the risk of ignition is minimised. For repair to the refrigerating system, the following precautions shall be complied with prior to conducting work on the system.
  - 6-2 **Work procedure**  
Work shall be undertaken under a controlled procedure so as to minimise the risk of flammable gas or vapour being present while the work is being performed.
  - 6-3 **General work area**
    - All maintenance staff and others working in the local area shall be instructed on the nature of work being carried out. Work in confined spaces shall be avoided.
    - The area around the workspace shall be sectioned off. Ensure that the conditions within the area have been made safe by control of flammable material.
  - 6-4 **Checking for presence of refrigerant**
    - The area shall be checked with an appropriate refrigerant detector prior to and during work, to ensure the technician is aware of potentially flammable atmospheres.
    - Ensure that the leak detection equipment being used is suitable for use with flammable refrigerants, i.e. non-sparking, adequately sealed or intrinsically safe.

# Safety Precautions

## CAUTION

### 6-5 Presence of fire extinguisher

- If any hot work is to be conducted on the refrigeration equipment or any associated parts, appropriate fire extinguishing equipment shall be available to hand.
- Have a dry powder or CO2 fire extinguisher adjacent to the charging area.

### 6-6 No ignition sources

- No person carrying out work in relation to a refrigeration system which involves exposing any pipe work that contains or has contained flammable refrigerant shall use any sources of ignition in such a manner that it may lead to the risk of fire or explosion.
- All possible ignition sources, including cigarette smoking, should be kept sufficiently far away from the site of installation, repairing, removing and disposal, during which flammable refrigerant can possibly be released to the surrounding space.
- Prior to work taking place, the area around the equipment is to be surveyed to make sure that there are no flammable hazards or ignition risks. "No Smoking" signs shall be displayed.

### 6-7 Ventilated area

- Ensure that the area is in the open or that it is adequately ventilated before breaking into the system or conducting any hot work.
- A degree of ventilation shall continue during the period that the work is carried out.
- The ventilation should safely disperse any released refrigerant and preferably expel it externally into the atmosphere.

### 6-8 Checks to the refrigeration equipment

- Where electrical components are being changed, they shall be fit for the purpose and to the correct specification.
- At all times the manufacturer's maintenance and service guidelines shall be followed. If in doubt consult the manufacturer's technical department for assistance.
- The following checks shall be applied to installations using flammable refrigerants:
  - The charge size is in accordance with the room size within which the refrigerant containing parts are installed;
  - The ventilation machinery and outlets are operating adequately and are not obstructed;
  - If an indirect refrigerating circuit is being used, the secondary circuit shall be checked for the presence of refrigerant;
  - Marking to the equipment continues to be visible and legible. Markings and signs that are illegible shall be corrected;
  - Refrigeration pipe or components are installed in a position where they are unlikely to be exposed to any substance which may corrode refrigerant containing components, unless the components are constructed of materials

# Safety Precautions

## CAUTION

which are inherently resistant to being corroded or are suitably protected against being so corroded.

### 6-9 Checks to electrical devices

- Repair and maintenance to electrical components shall include initial safety checks and component inspection procedures.
- If a fault exists that could compromise safety, then no electrical supply shall be connected to the circuit until it is satisfactorily dealt with.
- If the fault cannot be corrected immediately but it is necessary to continue operation, an adequate temporary solution shall be used.
- This shall be reported to the owner of the equipment so all parties are advised.
- Initial safety checks shall include:
  - That capacitors are discharged: this shall be done in a safe manner to avoid possibility of sparking;
  - That there no live electrical components and wiring are exposed while charging, recovering or purging the system;
  - That there is continuity of earth bonding.

### 7. Repairs to sealed components

- During repairs to sealed components, all electrical supplies shall be disconnected from the equipment being worked upon prior to any removal of sealed covers, etc.
- If it is absolutely necessary to have an electrical supply to equipment during servicing, then a permanently operating form of leak detection shall be located at the most critical point to warn of a potentially hazardous situation.
- Particular attention shall be paid to the following to ensure that by working on electrical components, the casing is not altered in such a way that the level of protection is affected.
- This shall include damage to cables, excessive number of connections, terminals not made to original specification, damage to seals, incorrect fitting of glands, etc.
- Ensure that apparatus is mounted securely.
- Ensure that seals or sealing materials have not degraded such that they no longer serve the purpose of preventing the ingress of flammable atmospheres.
- Replacement parts shall be in accordance with the manufacturer's specifications.

#### NOTE:

The use of silicon sealant may inhibit the effectiveness of some types of leak detection equipment. Intrinsically safe components do not have to be isolated prior to working on them.

### 8. Repair to intrinsically safe components

- Do not apply any permanent inductive or capacitance loads to the circuit without ensuring that this will not exceed the permissible voltage and current permitted for the equipment in use.
- Intrinsically safe components are the only types that can be worked on while

# Safety Precautions

## CAUTION

live in the presence of a flammable atmosphere. The test apparatus shall be at the correct rating.

- Replace components only with parts specified by the manufacturer.
- Other parts may result in the ignition of refrigerant in the atmosphere from a leak.

### 9. **Cabling**

- Check that cabling will not be subject to wear, corrosion, excessive pressure, vibration, sharp edges or any other adverse environmental effects.
- The check shall also take into account the effects of aging or continual vibration from sources such as compressors or fans.

### 10. **Detection of flammable refrigerants**

- Under no circumstances shall potential sources of ignition be used in the searching for or detection of refrigerant leaks.
- A halide torch (or any other detector using a naked flame) shall not be used.

### 11. **Leak detection methods**

- The following leak detection methods are deemed acceptable for systems containing flammable refrigerants:
  - Electronic leak detectors shall be used to detect flammable refrigerants, but the sensitivity may not be adequate, or may need re-calibration. (Detection equipment shall be calibrated in a refrigerant-free area.)
  - Ensure that the detector is not a potential source of ignition and is suitable for the refrigerant used.
  - Leak detection equipment shall be set at a percentage of the LFL of the refrigerant and shall be calibrated to the refrigerant employed and the appropriate percentage of gas (25 % maximum) is confirmed.
  - Leak detection fluids are suitable for use with most refrigerants but the use of detergents containing chlorine shall be avoided as the chlorine may react with the refrigerant and corrode the copper pipe-work.
  - If a leak is suspected, all naked flames shall be removed/ extinguished.
  - If a leakage of refrigerant is found which requires brazing, all of the refrigerant shall be recovered from the system, or isolated (by means of shut off valves) in a part of the system remote from the leak.
  - Oxygen free nitrogen (OFN) shall then be purged through the system both before and during the brazing process.

### 12. **Removal and evacuation**

- When breaking into the refrigerant circuit to make repairs – or for any other purpose – conventional procedures shall be used.
- However, it is important that best practice is followed since flammability is a consideration.
- The following procedure shall be adhered to:
  - Remove refrigerant;
  - Purge the circuit with inert gas;

# Safety Precautions

## CAUTION

- Evacuate;
- Purge again with inert gas;
- Open the circuit by cutting or brazing.
- The refrigerant charge shall be recovered into the correct recovery cylinders.
- The system shall be “flushed” with OFN to render the unit safe.
- This process may need to be repeated several times.
- Compressed air or oxygen shall not be used for this task.
- Flushing shall be achieved by breaking the vacuum in the system with OFN and continuing to fill until the working pressure is achieved, then venting to atmosphere, and finally pulling down to a vacuum.
- This process shall be repeated until no refrigerant is within the system. When the final OFN charge is used, the system shall be vented down to atmospheric pressure to enable work to take place.
- This operation is absolutely vital if brazing operations on the pipe-work are to take place.
- Ensure that the outlet for the vacuum pump is not close to any ignition sources and there is ventilation available.

### 13. Charging procedures

- In addition to conventional charging procedures, the following requirements shall be followed:
  - Ensure that contamination of different refrigerants does not occur when using charging equipment.
  - Hoses or lines shall be as short as possible to minimise the amount of refrigerant contained in them.
  - Cylinders shall be kept upright.
  - Ensure that the refrigeration system is earthed prior to charging the system with refrigerant.
  - Label the system when charging is complete (if not already).
  - Extreme care shall be taken not to overfill the refrigeration system.
- Prior to recharging the system it shall be pressure tested with OFN.
- The system shall be leak tested on completion of charging but prior to commissioning.
- A follow up leak test shall be carried out prior to leaving the site.

### 14. Decommissioning

- Before carrying out this procedure, it is essential that the technician is completely familiar with the equipment and all its detail.
- It is recommended good practice that all refrigerants are recovered safely.
- Prior to the task being carried out, an oil and refrigerant sample shall be taken in case analysis is required prior to re-use of reclaimed refrigerant. It is essential that electrical power is available before the task is commenced.
  - a) Become familiar with the equipment and its operation.
  - b) Isolate system electrically.

# Safety Precautions

## CAUTION

- c) Before attempting the procedure ensure that:
  - Mechanical handling equipment is available, if required, for handling refrigerant cylinders;
  - All personal protective equipment is available and being used correctly;
  - The recovery process is supervised at all times by a competent person;
  - Recovery equipment and cylinders conform to the appropriate standards.
- d) Pump down refrigerant system, if possible.
- e) If a vacuum is not possible, make a manifold so that refrigerant can be removed from various parts of the system.
- f) Make sure that cylinder is situated on the scales before recovery takes place.
- g) Start the recovery machine and operate in accordance with manufacturer's instructions.
- h) Do not overfill cylinders. (No more than 80 % volume liquid charge).
- i) Do not exceed the maximum working pressure of the cylinder, even temporarily.
- j) When the cylinders have been filled correctly and the process completed, make sure that the cylinders and the equipment are removed from site promptly and all isolation valves on the equipment are closed off.
- k) Recovered refrigerant shall not be charged into another refrigeration system unless it has been cleaned and checked.

### 15. Labelling

- Equipment shall be labelled stating that it has been de-commissioned and emptied of refrigerant.
- The label shall be dated and signed.
- Ensure that there are labels on the equipment stating the equipment contains flammable refrigerant.

### 16. Recovery

- When removing refrigerant from a system, either for servicing or decommissioning, it is recommended good practice that all refrigerants are removed safely.
- When transferring refrigerant into cylinders, ensure that only appropriate refrigerant recovery cylinders are employed.
- Ensure that the correct number of cylinders for holding the total system charge is available.
- All cylinders to be used are designated for the recovered refrigerant and labelled for that refrigerant (i.e. special cylinders for the recovery of refrigerant).
- Cylinders shall be complete with pressure relief valve and associated shut-off valves in good working order.
- Empty recovery cylinders are evacuated and, if possible, cooled before recovery occurs.
- The recovery equipment shall be in good working order with a set of

## Safety Precautions

### CAUTION

instructions concerning the equipment that is at hand and shall be suitable for the recovery of flammable refrigerants.

- In addition, a set of calibrated weighing scales shall be available and in good working order.
- Hoses shall be complete with leak-free disconnect couplings and in good condition.
- Before using the recovery machine, check that it is in satisfactory working order, has been properly maintained and that any associated electrical components are sealed to prevent ignition in the event of a refrigerant release.
- Consult manufacturer if in doubt.
- The recovered refrigerant shall be returned to the refrigerant supplier in the correct recovery cylinder, and the relevant Waste Transfer Note arranged.
- Do not mix refrigerants in recovery units and especially not in cylinders.
- If compressors or compressor oils are to be removed, ensure that they have been evacuated to an acceptable level to make certain that flammable refrigerant does not remain within the lubricant.
- The evacuation process shall be carried out prior to returning the compressor to the suppliers.
- Only electric heating to the compressor body shall be employed to accelerate this process.
- When oil is drained from a system, it shall be carried out safely.

### CAUTION

- When moving or relocating the air conditioner, consult experienced service technicians for disconnection and reinstallation of the unit.
- Do not place any other electrical products or household belongings under indoor unit or outdoor unit. Condensation dripping from the unit might get them wet, and may cause damage or malfunction of your property.
- Do not use means to accelerate the defrosting process or to clean, other than those recommended by the manufacturer.
- The appliance shall be stored in a room without continuously operating ignition sources (for example, open flames, an operating gas appliance or an operating electric heater).
- Do not pierce or burn.
- Be aware that refrigerants may not contain an odor.
- To keep ventilation openings clear of obstruction.
- The appliance shall be stored in a well-ventilated area where the room size corresponds to the room area as specified for operation.
- The appliance shall be stored in a room without continuously operating open flames (for example an operating gas appliance) and ignition sources (for example an operating electric heater).

## Safety Precautions

### CAUTION

- Any person who is involved with working on or breaking into a refrigerant circuit should hold a current valid certificate from an industry-accredited assessment authority, which authorises their competence to handle refrigerants safely in accordance with an industry recognised assessment specification.
- Servicing shall only be performed as recommended by the equipment manufacturer.
- Maintenance and repair requiring the assistance of other skilled personnel shall be carried out under the supervision of the person competent in the use of flammable refrigerants.
- Do not use means to accelerate the defrosting process or to clean, other than those recommended by the manufacturer.
- Appliance shall be installed, operated and stored in a room with a floor area larger than 10 m<sup>2</sup>.
- The installation of pipe-work shall be kept to a room with a floor area larger than 10 m<sup>2</sup>.
- The pipe-work shall be complied with national gas regulations.
- The maximum refrigerant charge amount is 2.5 kg. The specific refrigerant charge is based on the nameplate of the outdoor unit.
- Mechanical connectors used indoors shall comply with ISO 14903. When mechanical connectors are reused indoors, sealing parts shall be renewed. When flared joints are reused indoors, the flare part shall be re-fabricated.
- The installation of pipe-work shall be kept to a minimum.
- Mechanical connections shall be accessible for maintenance purposes.

### Precautions for using UV-C germicidal lamp systems (Optional)

### CAUTION

- This appliance contains a UV-C lamp;
- Read the maintenance instructions before opening the appliance;
- Unintended use of the appliance or damage to the housing can result in the escape of dangerous UV-C radiation. UV-C radiation may, even in small doses, cause harm to the eyes and skin;
- Appliances that are obviously damaged must not be operated;
- Before opening doors and access panels bearing the ultraviolet radiation hazard symbol for conducting the user maintenance, it is recommended to disconnect the power;
- Do not operate UV-C lamps outside of the appliance ;
- This UV-C lamp not allow user to clean and replace.

# Safety Precautions

Explanation of symbols displayed on the indoor unit or outdoor unit.

|                                                                                     |                |                                                                                                                                                                         |
|-------------------------------------------------------------------------------------|----------------|-------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
|    | <b>WARNING</b> | This symbol shows that this appliance uses a flammable refrigerant.<br>If the refrigerant is leaked and exposed to an external ignition source, there is a risk of fire |
|    | <b>CAUTION</b> | This symbol shows that the operation manual should be read carefully.                                                                                                   |
|    | <b>CAUTION</b> | This symbol shows that a service personnel should be handling this equipment with reference to the installation manual.                                                 |
|    | <b>CAUTION</b> | This symbol shows that information is available such as the operating manual or installation manual.                                                                    |
|  | <b>WARNING</b> | Turn off the UV lamp before opening.<br>Use UV radiation eye and skin protection during servicing.                                                                      |
| <b>A2L</b>                                                                          | <b>WARNING</b> | The refrigerant is named according to ASHRAE safety classification, with mild flammability and low toxicity.                                                            |

# Installation Instructions

## Suggested Tools

In order to install your air-conditioner more conveniently and safely, you might use those special tools listed below.



Standard Wrench



Screw Driver



Hex Keys or Allen Wrenches



Adjustable/Crescent Wrench



Torque wrench



Drill & Drill Bits



Manifold and Gauges



Vacuum Pump

Clamp on Amp Meter

Level

Work Gloves

Safety Glasses

Pipe Cutter

Refrigerant Scale

Flaring Tool

Micron Gauge

Hole Saw






# Installation Instructions

## Site Instructions


### Site for Installing Indoor Unit

- Where there is no obstacle near the air outlet and air can be easily blown to every corner.
- Where piping and wall hole can be easily arranged.
- Keep the required space from the unit to the ceiling and wall according to the installation diagram on previous page.
- Where the air filter can be easily removed.
- Keep the unit and remote controller 1m(3.28ft) or more apart from television, radio etc.
- keep as far as possible from fluorescent lamps.
- Do not put anything near the air inlet to obstruct it from air absorption.
- Install on a wall that is strong enough to bear the weight of the unit.
- Install in a place that will not increase operation noise and vibration.
- Keep away from direct sunlight and heating sources. Do not place flammable materials or combustion apparatuses on top of the unit.



### Site for Installing Outdoor Unit

- Where it is convenient to install and well ventilated.
- Avoid installing it where flammable gas could leak.
- Keep the required distance apart from the wall.
- Keep the outdoor unit away from greasy dirt, vulcanization gas exit.
- Avoid installing it by the roadside where there is a risk of muddy water.
- A fixed base where it is not subject to increased operation noise.
- Where there is not any blockage of the air outlet.
- Avoid installing under direct sunlight, in an aisle or sideway, or near heat sources and ventilation fans. Keep away from flammable materials, thick oil fog, and wet or uneven places.
- In case the pipe length is more than 7.5m(24.6ft), the refrigerant should be charged additionally, according to below table.



| Model  | Required amount of additional refrigerant (g/m) |
|--------|-------------------------------------------------|
| 9K-18K | 20                                              |
| 24K    | 30                                              |
| 36K    | 30                                              |

If the height or pipe length is out of the scope of the table, please consult the merchant.

# Installation Instructions

## Indoor Unit Installation

### 1. Installing the Mounting Plate

#### FOR the Ordinary Mounting Plate


- Decide an installing location for the mounting plate according to the indoor unit location and piping direction.

**Note:** it is recommended to install screw anchors for sheet rock, concrete block, brick and such type of wall.

- Keep the mounting plate horizontal with a horizontal level or dropping line.
- Mark the center of the indoor unit on mounting plate for future reference.

**Note:** the center of the mounting bracket may be not the center of the indoor unit.


- Tapping mounting plate to the wall with a minimum of five screws, evenly spaced to properly support indoor unit weight.



**Note:** The shape of your mounting plate may be different from the one above, but the installation method is similar.

**Note:** As the above figure shown, the six holes matched with tapping screw on the mounting plate must be used to fix the mounting plate, the others are prepared.


#### MOUNTING BRACKET DIAGRAMS AND DIMENSIONS (Recommended)




# Installation Instructions

## FOR the Ordinary Mounting Plate

### MOUNTING BRACKET DIAGRAMS AND DIMENSIONS (Recommended)



WIDTH: 629mm/24.8in



WIDTH: 820mm/32.3in

# Installation Instructions

## Indoor Unit Installation

### FOR the Wooden Wall Mounting Plate



- Decide an installing location for the mounting plate according to the indoor unit location and piping direction.

**Note:** *it is recommended to install screw anchors for sheet rock, concrete block, brick and such type of wall.*

- Keep the mounting plate horizontal with a horizontal level or dropping line.
- Mark the center of the indoor unit on mounting plate for future reference.

**Note:** *the center of the mounting bracket may be not the center of the indoor unit.*


- Tapping mounting plate to the wall with a minimum of five screws, evenly spaced to properly support indoor unit weight.



**Note:** *The shape of your mounting plate may be different from the one above, but the installation method is similar.*

**Note:** *As the above figure shown, the six holes matched with tapping screw on the mounting plate must be used to fix the mounting plate, the others are prepared.*


### MOUNTING BRACKET DIAGRAMS AND DIMENSIONS (Recommended)




# Installation Instructions

## FOR the Wooden Wall Mounting Plate

### MOUNTING BRACKET DIAGRAMS AND DIMENSIONS (Recommended)



WIDTH: 629mm/24.8in



WIDTH: 820mm/32.3in

# Installation Instructions

## Indoor Unit Installation

### 2. Drill a Hole in wall for interconnecting Piping, Drain & Wiring

- Decide the position of the hole for piping according to the location of mounting plate.
- Drill a hole in the wall. The hole should tilt a little downward toward outside.
- Install a sleeve through the wall hole to keep the wall tidy and clean.




**Table of Wall Hole Mounting size per Unit Size**

|  | Size A  | Size B    | Size C |
|--|---------|-----------|--------|
|  | mm/in   | mm/in     | mm/in  |
|  | 68/2.68 | 33/1.3    | 70/2.7 |
|  | 70/2.75 | 35/1.38   | 70/2.7 |
|  | 137/5.4 | 40/1.57   | 70/2.7 |
|  | 170/6.7 | 40/1.57   | 70/2.7 |
|  | 64/2.52 | 41.2/1.62 | 70/2.7 |

### 3. Piping and Drain Hose Connections to Indoor Unit

- Put the piping (liquid and gas pipe) and cables through the wall hole from outside or put them through from inside after indoor piping and cables connection is complete to connect to the outdoor unit.
- Decide whether to saw the unloading piece off in accordance with the piping direction.(as shown below)



- After connecting the piping, install the drain hose. Then connect the power cords. After connecting, wrap the piping, cords and drain hose together with thermal insulation materials.


**Note:** Both sides drainage structure is standard. For both sides drainage structure, it can be chosen for right, left or both sides drainage connection. If choosing both sides drainage connection, another proper drain hose is needed as there is only one drain hose offered by factory. If choosing one side drainage connection, make sure the drain hole on the other side is well plugged.

# Installation Instructions


## Indoor Unit Installation

### • Piping Joints Thermal Insulation:

Wrap the piping joints with thermal insulation materials and then wrap with a vinyl tape.



Thermal insulation



wrapped with vinyl tape



### • Piping Thermal Insulation:

a. Place the drain hose under the piping.

b. Insulation material uses polythene foam over 6mm in thickness.

**Note:** Drain hose is prepared by user.

- Do not arrange the drain pipe in a way that leaves it twisted, sticking out or waving around. Do not immerse the end of it in water.
- If an extension drain hose is connected to the drain pipe, make sure to insulated when passing along the indoor unit.
- When the piping is directed to the right, piping, power Cord and drain pipe should be thermal insulated and fixed onto the back of the unit with a piping fixer.




A. Insert the pipe fixer to the slot.

B. Press to hook the pipe fixer onto the base.

### Piping Connection:

- Before unscrewing the big and the small sealing caps, press the small sealing cap with the finger until the exhaust noise stops, and then loosen the finger.
- Connect indoor unit pipes with two wrenches. Pay special attention to the allowed torque as shown below to prevent the pipes, connectors and flare nuts from being deformed and damaged.
- Pre-tighten them with fingers at first, then use the wrenches.



☑ If you don't hear the exhaust noise, please contact with the merchant.

| Model   | Pipe size                          | Torque                  | Nut width  | Min.thickness |
|---------|------------------------------------|-------------------------|------------|---------------|
| 9K-18K  | Liquid Side ( $\phi$ 6 or 1/4 )    | 15~20N·m or 11~15ft-lbs | 17 or 5/8  | 0.5 or 0.02   |
| 24K-36K | Liquid Side ( $\phi$ 9.53 or 3/8 ) | 30~35N·m or 22~26ft-lbs | 22 or 7/8  | 0.6 or 0.024  |
| 9K-12K  | Gas Side ( $\phi$ 9.53 or 3/8 )    | 30~35N·m or 22~26ft-lbs | 22 or 7/8  | 0.6 or 0.024  |
| 18K     | Gas Side ( $\phi$ 12 or 1/2 )      | 50~55N·m or 37~41ft-lbs | 24 or 0.94 | 0.6 or 0.024  |
| 24K     | Gas Side ( $\phi$ 16 or 5/8 )      | 60~65N·m or 44~48ft-lbs | 27 or 1.1  | 0.6 or 0.024  |



### NOTE:


Dimensions are in "mm or inch" unless otherwise stated in the table.

# Installation Instructions

## Outdoor Unit Installation

### 1. Install Condensate Drain for Outdoor Unit

The condensate drains from the outdoor unit when the unit operates in heating mode. In order not to disturb your neighbor and protect the environment, install a drain port and a drain hose to direct the condensate water. Just install the drain port and rubber washer to the chassis of the outdoor unit, then connect a drain hose to the port as the following figure demonstrates.



### 2. Install Ground Pad or Wall Hangers

1. Determine proper location for outdoor unit.
  2. Follow all instructions provided by manufacturer for installing wall hangers rubber pad.
  3. Verify the wall hangers or rubber pad can safely support the weight of the outdoor unit.
  4. Verify the wall hangers or rubber pad is level and meets all outdoor dimensional clearance.
  5. Fix with bolts and nuts tightly on a flat and strong floor.
- If installed on the wall or roof, make sure to fix the supporter well to prevent it from shaking due to serious vibration or strong wind.


## **WARNING**

Florida wind load requirements state that outdoor unit must be anchored to concrete pad using four 3/8-in diameter power wedge bolt plus(or equivalent) with 1-in diameter fender washers. Anchor bolts must be embedded into 3000 PSI minimum concrete at a distance of 4 1/2- in from any concrete edge. The concrete thickness must exceed 1.5 times the anchor depth.

# Installation Instructions

## 3. Piping Connections to Outdoor Unit

- Remove service valve cover( if provided) to access the service valves and refrigerant ports.
- Carefully bend and adjust length of refrigerant pipes to meet outdoor unit service valves connection with proper tools to avoid kinks.
- Apply a small amount of refrigerant oil to the flare connection on the refrigerant pipe.
- Properly align piping and tighten flare nut using a standard wrench and a torque wrench as shown in the indoor piping section.
- Carefully tighten flare nuts to correct torque level referring to the following Torque Table:



*Torque Table*

| Pipe diameter<br>/inch(mm) | Nut Size<br>/inch(mm) | Tightening Torque |          |
|----------------------------|-----------------------|-------------------|----------|
|                            |                       | ft-lbs            | N-m      |
| 1/4(6.35)                  | 1/4(17)               | 11 to 15          | 15 to 20 |
| 3/8(9.5)                   | 3/8(22)               | 22 to 26          | 30 to 35 |
| 1/2(12.7)                  | 1/2(25)               | 37 to 41          | 50 to 55 |
| 5/8(15.9)                  | 5/8(29)               | 44 to 48          | 60 to 65 |
| 3/4(19)                    | 3/4(32)               | 52 to 55          | 70 to 75 |

**Note:** Over tightening may damage flare connections and cause leaks.

# Installation Instructions

## Power and Wiring

### Connecting of the Cable

#### • Indoor Unit

Connect the power cord to the indoor unit by connecting the wires to the terminals on the control board individually in accordance with the outdoor unit connection.

**Note:** For some models, it is necessary to remove the cabinet to connect to the indoor unit terminal.

#### • Outdoor Unit

1) Remove the cable cross board from the unit by loosening the screw. Connect the wires to the terminals on the control board individually as follows.

2) Secure the power cord onto the control board with cable clamp.

3) Reinstall the cable cross board to the original position with the screw.

4) Use a recognized circuit breaker between the power source and the unit. A disconnecting device to adequately disconnect all supply lines must be fitted.

#### Caution:


1. Never fail to have an individual power circuit specifically for the air conditioner. As for the method of wiring, refer to the circuit diagram posted on the inside of the access door.
2. Confirm that the cable thickness is as specified in the power source specification.
3. Check the wires and make sure that they are all tightly fastened after cable connection.
4. Be sure to install an earth leakage circuit breaker in wet or moist areas.

#### Cable Specifications

| capacity(Btuh)    | Power cord |                              | Power connecting cord |                              |
|-------------------|------------|------------------------------|-----------------------|------------------------------|
|                   | Type       | Normal cross-sectional areas | Type                  | Normal cross-sectional areas |
| 9K-12K(208/230V)  | SJ TW      | 3X16 AWG                     | SJ TW                 | 4X18 AWG                     |
| 18K(208/230V)     | SJ TW      | 3X14 AWG                     | SJ TW                 | 4X18 AWG                     |
| 24K-36K(208/230V) | SJ TW      | 3X12 AWG                     | SJ TW                 | 4X18 AWG                     |
| 9K,12K(115V)      | SJ TW      | 3X14 AWG                     | SJ TW                 | 4X18 AWG                     |

#### Attention:

The plug must be accessible even after the installation of the appliance in case there is a need to disconnect it. If not possible, connect appliance to a double-pole switching device with contact separation of at least 3 mm placed in an accessible position even after installation.



# Installation Instructions

## Wiring Diagram

### Warning:


**Before obtaining access to terminals, all supply circuits must be disconnected.**

**Make sure that the color of the wires in the outdoor unit and terminal No. are the same as those of the indoor unit, the details please refer to the wiring diagram which is near the terminal inside the unit.**

## Vacuum Testing and Charging

The air which contains moisture remaining in the refrigeration cycle may cause a malfunction on the compressor. After connecting the indoor and outdoor units, release air and moisture from the refrigerant cycle using a vacuum pump, as shown below.

Note: To protect the environment, be sure not to discharge the refrigerant to the air directly.  
See next page for air purging steps.



### How to Vacuum Air Tubes:

- (1) Unscrew and remove caps from 2 and 3-way valves.
- (2) Unscrew and remove cap from service valve.
- (3) Connect vacuum pump flexible hose to the service valve.
- (4) Start vacuum pump for 10-15 minutes until reaching a vacuum of 10 mm Hg absolutes.
- (5) With vacuum pump still running close the low pressure knob on vacuum pump manifold. Then stop the vacuum pump.
- (6) Open 2-way valve ,1/4 turn, then close it after 10 seconds. Check tightness of all joints using liquid soap or an electronic leak detector.
- (7) Turn 2 and 3-way valves stem to fully open the valves. Disconnect the flexible vacuum pump hose.
- (8) Replace and tighten all valve caps.

# ***Installation Instructions***

## **Start-up**

### ***Test Operation***

Perform test operation after completing gas leak and electrical safety check.

1. Turn on electrical disconnect to outdoor unit.
2. Push the "ON/OFF" button on Remote Controller to begin testing.
3. Push MODE button, select COOLING, HEATING, FAN mode to confirm all functions.

### ***System Checks***

1. Conceal refrigerant pipes where possible.
2. Make sure drain hose slopes downward along entire length.
3. Ensure all refrigerant pipes and connections are properly insulated.
4. Fasten pipes to outside wall, when possible.
5. Seal and weatherproof wall hole which the interconnecting wires and refrigerant pipes pass through.

### ***Indoor Unit***

1. Do all Remote controller's buttons function properly?
2. Do the display panel lights work properly?
3. Does the swing louver function properly?
4. Does the drain work?

### ***Outdoor Unit***

1. Push the mode button to COOL and adjust the room setting to 61 °F(16°C) deg. wait up to 3 minutes from compressor time guard. Does compressor and outdoor fan turn on in cooling mode?
2. Push the mode button to HEAT and adjust the room setting to 86 °F(30°C) deg. wait up to 3 minutes for compressor time guard. Does compressor and outdoor fan turn on in heat mode?


# Care and Maintenance

## Front panel maintenance

1

### Cut off the power supply

Turn off the appliance first before disconnecting from power supply.



2

Grasp position "a" and pull outward to remove the front panel.



3

### Wipe with a soft and dry cloth.

Use soft moisture cloth to clean if the front panel is very dirty.



Use a dry and soft cloth to clean it.

4

Never use volatile substance such as gasoline or polishing powder to clean the appliance.



5

Never sprinkle water onto the indoor unit



Dangerous!  
Electric shock!

6

### Reinstall and shut the front panel.

Reinstall and shut the front panel by pressing position "b" downward.



## Air filter maintenance

It is necessary to clean the air filter after using it for about 200 hours.

Clean it as follows:

1

### Stop the appliance and remove the air filter.



1. Open the front panel.
2. Press the handle of the filter gently from the front.
3. Grasp the handle and slide out the filter.

2

### Clean and reinstall the air filter.

If the dirt is conspicuous, wash it with a solution of detergent in lukewarm water. After cleaning, dry well in shade.



3

### Close the front panel again.

- ☑ Clean the air filter every two weeks if the air conditioner operates in an extremely dusty environment.

# Protection

## ♦ Operating condition

### Operating temperature

| Temperature         |     | Cooling operation | Heating operation | Drying operation |
|---------------------|-----|-------------------|-------------------|------------------|
| Indoor temperature  | max | 90°F ( 32°C )     | 81°F ( 27°C )     | 90°F ( 32°C )    |
|                     | min | 70°F ( 21°C )     | 45°F ( 7°C )      | 64°F(18°C)       |
| Outdoor temperature | max | 115°F ( 46°C )    | 75°F ( 24°C)      | 115°F ( 46°C )   |
|                     | min | *note             | -4°F(-20°C )      | 70°F ( 21°C )    |

#### NOTE:

\*Optimum performance will be achieved within these operating temperature. If air conditioner is used outside of the above conditions, the protective device may trip and stop the appliance.

\*For Tropical (T3) Climate condition models, the outdoor max temperature is 131°F ( 55 °C ) instead of 115°F(46 °C).

\*For some models, can keep cooling at 5°F(-15 °C) outdoor ambient via unique design. Normally, optimum cooling performance will be achieved above 70°F(21 °C). Please consult the merchant to get more information.

\*For R32 refrigerant models can keep heating at -4°F(-20 °C) outdoor ambient , for R454B refrigerant models can keep heating at -13°F(-25 °C) outdoor ambient. For some models, can keep heating even at lower outdoor ambient  
The temperature of some products is allowed beyond the range. In specific situation, please consult the merchant. When relative humidity is above 80%, if the air conditioner runs in COOLING or DRY mode with door or window opened for a long time, dew may drip down from the outlet.

## ♦ Noise pollution

- Install the air conditioner at a place that can bear its weight in order to operate more quietly.
- Install the outdoor unit at a place where the air discharged and the operation noise would not annoy your neighbors.
- Do not place any obstacles in front of the air outlet of the outdoor unit lest it increases the noise level.

## ♦ Features of protector

1. The protective device will work at following cases.
  - Restarting the unit at once after operation stops or changing mode during operation, you need to wait for 3 minutes.
  - Connect to power supply and turn on the unit at once, it may start 20 seconds later.
2. If all operation has stopped, press **ON/OFF** button again to restart, Timer should be set again if it has been canceled.

## ♦ Features of HEATING mode

### Preheat

At the beginning of the HEATING operation, the airflow from the indoor unit is discharged 2-5 minutes later.

### Defrost

In **HEATING** operation the appliance will defrost (de-ice) automatically to raise efficiency. This procedure usually lasts 2-10 minutes. During defrosting, fans stop operation. After defrosting completes, it returns to **HEATING** mode automatically.

**Note: Heating is NOT available for cooling only air conditioner models.**

## ***Energy Saving Tips***

---

**1. Relaxing room temperature at night is OK:** During the nighttime hours you don't require the same level of conscious cooling or heating. Try using Sleep mode to gradually relax room temperature and allow the unit to run less and save energy.

**2. Curtains and shades:** In the summer, you need to block the effects of the sun. Close window curtains and shades on the south and west side of your home to help block solar heat. In winter, the sun is your friend. Open curtains and shades to allow solar heat into your room.

**3. Close doors:** If you don't need to heat and cool your whole home, confine the heating and cooling to one room by closing doors. Limit the space you're heating and cooling to specified capability of the unit.

**4. Service the unit:** Some basic maintenance might be all you need. The outdoor unit will greatly benefit from a good hosing out, especially in treed areas where seeds and other debris can stick to coil fins and make the unit work harder!

**5. Rearrange the room:** Furniture that obstructs airflow means you could be heating and cooling the back of a chair or the front of a sofa instead of the actual living space. Use the swing louvers to help direct the air in the right direction for the room; remove or rearrange obstacles blocking airflow.

**6. Try 75 degrees:** 75°F(24°C) is a good point for an air conditioner to run at its optimal performance level. Even a 1-degree change in temperature can make your unit use more energy!







**7. Lighting:** Turning lights off can help reduce your heat. Each light bulb is a tiny heater. Your air conditioner must waste energy overcoming the heat from your lights to reach and hold your desired room temperature.

**8. Is anyone home?** If possible, while you're away turn your unit to Auto mode and make sure windows and drapes are closed. Although the room temperature will be uncomfortable for a few minutes when you come home, the unit will have the room back to your desired temperature in no time.

**9. Don't forget the fan:** The fan is much like a car. The faster it runs, the more energy is consumed. Sometimes we need the car to go fast, but slow is good enough most of the time. Try saving money by using the comfortable quiet low fan speed as much as possible.

# Troubleshooting


The following cases may not always be a malfunction, please check it before asking for service.

| Trouble                                                                                                                  | Analysis                                                                                                                                                                                                                                                                                                                 |
|--------------------------------------------------------------------------------------------------------------------------|--------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| <p>Does not run</p>                     | <ul style="list-style-type: none"> <li>• If the protector trip or fuse is blown, please wait 3 minutes and start again. The protector device may be preventing unit from working.</li> <li>• The batteries in the remote control may be dead</li> <li>• Check to see if the appliance is properly plugged in.</li> </ul> |
| <p>No cooling or heating air</p>        | <ul style="list-style-type: none"> <li>• Is the air filter dirty?</li> <li>• Are the intakes and outlets of the air conditioner blocked?</li> <li>• Is the temperature set properly?</li> <li>• Are doors or windows open?</li> </ul>                                                                                    |
| <p>Ineffective control</p>             | <ul style="list-style-type: none"> <li>• If there is strong interference (from excessive static electricity discharge or power supply voltage abnormality), the appliance may operate abnormally. Disconnect the power supply and connect back 2-3 seconds later.</li> </ul>                                             |
| <p>Does not operate immediately</p>   | <ul style="list-style-type: none"> <li>• Changing mode during operation, 3 minutes will delay.</li> </ul>                                                                                                                                                                                                                |
| <p>Peculiar odor</p>                  | <ul style="list-style-type: none"> <li>• This odor may come from another source such as furniture, cigarette etc, which is sucked in the unit and blows out with the air.</li> </ul>                                                                                                                                     |
| <p>A sound of flowing water</p>       | <ul style="list-style-type: none"> <li>• Caused by the flow of refrigerant in the air conditioner. Not a cause for concern.</li> <li>• Sound of defrosting during heating mode.</li> </ul>                                                                                                                               |
| <p>Cracking sound is heard</p>        | <ul style="list-style-type: none"> <li>• The sound may be generated by the expansion or contraction of the front panel due to change of temperature.</li> </ul>                                                                                                                                                          |
| <p>Spraying mist from the outlet</p>  | <ul style="list-style-type: none"> <li>• Mist appears when the air in the room becomes very cold. This is because of the cool air discharged from the indoor unit during COOLING or DRY modes.</li> </ul>                                                                                                                |
| <p>The compressor indicator lights on constantly, running indicator flashes and indoor fan stops.</p>                    | <ul style="list-style-type: none"> <li>• The unit is shifting from heating mode to defrost. The indicator will light off and return to heating mode.</li> </ul>                                                                                                                                                          |

# Display introduction


|                                                                                     |                                                                                                                                                                                                                                                                                             |           |
|-------------------------------------------------------------------------------------|---------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|-----------|
|    | <b>Temperature indicator</b> ..... 1<br>Display set temperature.<br>It shows FC after 200 hours of usage as reminder to clean the filter.<br>After filter cleaning press the filter reset button located on the indoor unit behind the front panel in order to reset the display.(optional) | <b>1</b>  |
|    | <b>Running indicator</b> ..... 2<br>It lights up when the AC is running.<br>It flashes during defrosting.                                                                                                                                                                                   | <b>2</b>  |
|    | <b>Timer indicator</b> ..... 3<br>It lights up during set time.                                                                                                                                                                                                                             | <b>3</b>  |
|    | <b>Sleep indicator</b> ..... 4<br>It lights up in sleep mode.                                                                                                                                                                                                                               | <b>4</b>  |
|    | <b>Compressor indicator</b> ..... 5<br>It lights up when the compressor is on.                                                                                                                                                                                                              | <b>5</b>  |
|   | <b>Mode indicator</b> ..... 6<br>Heating displays orange,others display white                                                                                                                                                                                                               | <b>6</b>  |
|  | <b>Fan speed indicator</b> ..... 7                                                                                                                                                                                                                                                          | <b>7</b>  |
|  | <b>Signal Receptor</b> ..... 8                                                                                                                                                                                                                                                              | <b>8</b>  |
|  | <b>Smart WIFI indicator</b> ..... 9<br>It lights up during WIFI is on.                                                                                                                                                                                                                      | <b>9</b>  |
|                                                                                     | <b>NANOE indicator</b> ..... 10<br>It lights up in NANOE mode.                                                                                                                                                                                                                              | <b>10</b> |

Emergency button **A**



**ON/OFF** To let the AC run or stop by pressing the button.

**QA/QB series**



☑ The symbols may be different from these models, but the functions are similar.



