



## MS09TW (W)

## 13-1. INDOOR UNIT STRUCTURAL PARTS



## 13-2. ACCESSORY AND REMOTE CONTROLLER



## 13-1. INDOOR UNIT STRUCTURAL PARTS


| No. | Parts No.   | Parts Name              | Symbol<br>in Wiring<br>Diagram | Q'ty / set    | Remarks         |
|-----|-------------|-------------------------|--------------------------------|---------------|-----------------|
|     |             |                         |                                | MS09TW<br>(W) |                 |
| 1   | E02 408 970 | INSTALLATION PLATE      |                                | 1             |                 |
| 2   | E02 409 234 | BOX(W)                  |                                | 1             |                 |
| 3   | E02 409 976 | CORNER BOX LEFT (W)     |                                | 1             |                 |
| 4   | E02 424 000 | FRONT PANEL ASSEMBLY(W) |                                | 1             | Including 5,6,7 |
| 5   | E02 409 067 | SCREW CAP(W)            |                                | 2             | 2PCS/SET        |
| 6   | E02 424 010 | GRILLE (W)              |                                | 1             |                 |
| 7   | E02 408 142 | CATCH (W)               |                                | 3             | 3PCS/SET        |
| 8   | E02 408 100 | AIR FILTER              |                                | 2             |                 |
| 9   | E02 409 975 | CORNER BOX RIGHT (W)    |                                | 1             |                 |

## 13-2. ACCESSORY AND REMOTE CONTROLLER

|    |             |                          |  |   |  |
|----|-------------|--------------------------|--|---|--|
| 10 | E02 541 426 | REMOTE CONTROLLER        |  | 1 |  |
| 11 | E02 527 083 | REMOTE CONTROLLER HOLDER |  | 1 |  |

## MS09TW (W)

### 13-3. INDOOR UNIT ELECTRICAL PARTS AND FUNCTIONAL PARTS



### 13-3. INDOOR UNIT ELECTRICAL PARTS AND FUNCTIONAL PARTS

| No. | Parts No.   | Parts Name                   | Symbol in Wiring Diagram | Q'ty / set | Remarks      |
|-----|-------------|------------------------------|--------------------------|------------|--------------|
|     |             |                              |                          | MS09TW (W) |              |
| 1   | E02 408 302 | LINE FLOW FAN                |                          | 1          |              |
| 2   | E02 408 509 | BEARING MOUNT                |                          | 1          |              |
| 3   | E02 001 504 | SLEEVE BEARING               |                          | 1          |              |
| 4   | E02 408 702 | DRAIN HOSE                   |                          | 1          |              |
| 5   | E02 409 235 | NOZZLE (W)                   |                          | 1          |              |
| 6   | E02 409 040 | VANE UPPER (W)               |                          | 1          |              |
| 7   | E02 409 041 | VANE LOWER (W)               |                          | 1          |              |
| 8   | E02 268 382 | FUSE                         | F11                      | 1          | 250V/3.0A    |
| 9   | E02 268 385 | VARISTOR                     | NR11                     | 1          |              |
| 10  | E02 408 034 | VANE CRANK SET               |                          | 1          |              |
| 11  | E02 541 452 | ELECTRONIC CONTROL P.C.BOARD |                          | 1          | AUTO RESTART |
| 12  | E02 408 303 | VANE MOTOR                   | MV                       | 1          |              |
| 13  | E02 541 308 | ROOM TEMPERATURE THERMISTOR  | RT11                     | 1          |              |
| 14  | E02 268 300 | INDOOR FAN MOTOR             | MF                       | 1          | RC4W19- □ □  |
| 15  | E02 541 375 | TERMINAL BLOCK               | TB                       | 1          |              |
| 16  | E02 151 505 | FAN MOTOR RUBBER MOUNT       |                          | 2          | 2PCS/SET     |
| 17  | E02 408 307 | INDOOR COIL THERMISTOR       | RT12                     | 1          |              |
| 18  | E02 408 333 | MOTOR BAND                   |                          | 1          |              |

### 13-4. INDOOR UNIT HEAT EXCHANGER

|    |             |                       |  |   |      |
|----|-------------|-----------------------|--|---|------|
| 19 | E02 462 620 | INDOOR HEAT EXCHANGER |  | 1 |      |
| 20 | E02 151 667 | UNION(LIQUID)         |  | 1 | φ1/4 |
| 21 | E02 151 666 | UNION(GAS)            |  | 1 | φ3/8 |